



BOMAG

FAYAT GROUP

Operating Instruction Maintenance Instruction

Original Operating Instructions

**BW 80/90 AD-5 / BW 100 ADM/ACM-5 /
BW 90/100 SC-5 / BW 100 SCC-5**



S/N 101 462 00 3159> / S/N 101 462 01 1943> / S/N 101 462 03 2126> / S/N 101 462 04 1199> /
S/N 101 462 05 1196> / S/N 101 462 06 1075> / S/N 101 462 07 1090>

Tandem vibratory roller

Combination roller

Table of contents

1	Foreword.....	7
1.1	Machine type plate and engine type plate.....	10
2	Technical data.....	11
2.1	Technical data BW 80 AD-5.....	12
2.1.1	Noise and vibration data.....	15
2.2	Technical data BW 90 AD-5.....	17
2.2.1	Noise and vibration data.....	20
2.3	Technical data BW 100 ADM-5.....	22
2.3.1	Noise and vibration data.....	25
2.4	Technical data BW 90 SC-5.....	27
2.4.1	Noise and vibration data.....	30
2.5	Technical data BW 100 SC-5.....	32
2.5.1	Noise and vibration data.....	35
2.6	Technical data BW 100 ACM-5.....	37
2.6.1	Noise and vibration data.....	40
2.7	Technical data BW 100 SCC-5.....	42
2.7.1	Noise and vibration data.....	45
3	Safety regulations.....	47
4	Indicators and control elements.....	73
4.1	General notes.....	75
4.2	Description of indicators and control elements.....	76
4.3	Instrument cluster.....	87
5	Operation.....	89
5.1	General.....	90
5.2	Checks prior to start up.....	91
5.3	Electronic immobilizer.....	93
5.4	Adjusting the driver's seat.....	94
5.5	Starting the engine.....	95
5.6	Driving the machine.....	98
5.6.1	Seat contact switch.....	100
5.7	Stopping the machine, operating the parking brake.....	102
5.8	Shutting down the engine.....	103
5.9	Switching the vibration on/off.....	105

Table of contents

5.9.1	Preliminary remarks and safety notes.....	105
5.9.2	Vibration in manual mode.....	106
5.9.3	Vibration in automatic mode.....	107
5.10	Operating the Economizer	109
5.11	Switching the pressure sprinkling system on and off.....	113
5.12	Switching emulsion sprinkling on/off	116
5.13	Setting the crabwalk.....	117
5.14	What to do in events of emergency.....	119
5.15	Mounting the edge cutter tool.....	121
5.16	Lifting / lowering the edge cutter.....	122
5.17	Connecting/disconnecting the hydraulic breaker^{Optional equip-} ment	123
5.18	Towing.....	126
5.18.1	Towing AD/ADM/SC-machines.....	126
5.18.2	Towing ACM/SCC-machines.....	129
5.19	Loading/transport.....	132
6	Maintenance.....	139
6.1	General notes on maintenance.....	140
6.2	Fuels and lubricants.....	144
6.2.1	Engine oil.....	144
6.2.2	Fuel.....	145
6.2.3	Coolant.....	147
6.2.4	Hydraulic oil.....	148
6.3	List of fuels and lubricants.....	150
6.4	Running-in instructions.....	152
6.5	Maintenance Table.....	153
6.6	Every 10 operating hours.....	155
6.6.1	Check the engine oil level.....	155
6.6.2	Check the fuel level.....	156
6.6.3	Checking the hydraulic oil level	157
6.6.4	Checking the hydraulic oil filter element.....	158
6.6.5	Checking the coolant level.....	159
6.6.6	Checking the water level.....	160
6.6.7	Check the emulsion level.....	160
6.7	Every 50 operating hours.....	162

6.7.1	Checking, cleaning the air filter, replacing if necessary.....	162
6.7.2	Check fuel lines and clamps.....	165
6.7.3	Checking, cleaning the water separator.....	166
6.8	Every 250 operating hours.....	167
6.8.1	Changing engine oil and oil filter cartridge.....	167
6.8.2	Checking, tensioning, replacing the V-belt.....	169
6.8.3	Checking the air intake lines.....	170
6.8.4	Cleaning radiator and hydraulic oil cooler.....	171
6.8.5	Battery service.....	173
6.8.6	Checking radiator hoses and hose clamps.....	175
6.8.7	Check scrapers, adjust if necessary.....	176
6.9	Every 500 operating hours.....	178
6.9.1	Drain the fuel tank sludge.....	178
6.9.2	Change the fuel filter.....	179
6.9.3	Check the anti-freeze concentration and the condition of the coolant.....	180
6.10	Every 1000 operating hours.....	182
6.10.1	Checking, adjusting the valve clearance.....	182
6.10.2	Check the engine mounts.....	184
6.10.3	Check the travel control.....	184
6.11	Every 2000 operating hours.....	185
6.11.1	Changing hydraulic oil and breather filter.....	185
6.11.2	Replacing the hydraulic oil filter.....	189
6.11.3	Changing the coolant.....	190
6.11.4	Replacing the fuel lines.....	193
6.11.5	Check the injection nozzles.....	194
6.12	Every 3000 operating hours.....	195
6.12.1	Check the fuel injection pump.....	195
6.13	As required.....	196
6.13.1	Checking the air pressure in the rubber tires.....	196
6.13.2	Water sprinkler system, maintenance in case of frost.....	196
6.13.3	Tightening torques for screws with metric unified thread.....	198
6.13.4	Measures to be applied for longer periods of rest.....	198
7	Trouble shooting.....	201
7.1	General notes.....	202

Table of contents

7.2	Starting with jump wires.....	203
7.3	Engine problems	205
7.4	Fuse assignment.....	207
7.4.1	Notes on safety.....	207
7.4.2	Central electrics.....	207
7.4.3	Main battery fuse.....	209
8	Disposal.....	211
8.1	Final shut-down of machine.....	212

BOMAG manufactures machine for earth, asphalt and refuse compaction, stabilizers/recyclers as well as milling machine and finishers.

BOMAG's vast experience in connection with state-of-the-art production and testing methods, such as lifetime tests of all important components and highest quality demands guarantee maximum reliability of your machine.

This manual comprises:

- Safety regulations
- Operating instructions
- maintenance instructions
- Trouble shooting

Using these instructions will

- help you to become familiar with the machine.
- avoid malfunctions caused by unprofessional operation.

Compliance with the maintenance instructions will

- enhance the reliability of the machine on construction sites,
- prolong the lifetime of the machine,
- reduce repair costs and downtimes.

BOMAG will not assume liability for the function of the machine

- if it is handled in a way not complying with the usual modes of use,
- if it is used for purposes other than those mentioned in these instructions.

No warranty claims can be lodged in case of damage resulting from

- operating errors,
- insufficient maintenance and
- wrong fuels and lubricants.

Please note!

This manual was written for operators and maintenance personnel on construction sites.

Always keep this manual close at hand, e.g. in the tool compartment of the machine or in a specially provided container. These operating and maintenance instructions are part of the machine.

You should only operate the machine after you have been instructed and in compliance with these instructions.

Strictly observe the safety regulations.

Please observe also the guidelines of the Civil Engineering Liability Association "Safety Rules for the Operation of Road Rollers and Soil Compactors" and all relevant accident prevention regulations.

For your own personal safety you should only use original spare parts from BOMAG.

For your machine BOMAG offers service kits to make maintenance easier.

In the course of technical development we reserve the right for technical modifications without prior notification.

These operating and maintenance instructions are also available in other languages.

Apart from that, the spare parts catalogue is available from your BOMAG dealer against the serial number of your machine.

Foreword – Machine type plate and engine type plate

Your BOMAG dealer will also supply you with information about the correct use of our machines in soil and asphalt construction.

The above notes do not constitute an extension of the warranty and liability conditions specified in the general terms of business of BOMAG.

We wish you successful work with your BOMAG machine.

BOMAG GmbH

Copyright by BOMAG

1.1 Machine type plate and engine type plate




Fig. 1: Machine type plate (example)

Please enter here:

Machine type (1):

Serial number (2):




Fig. 2: Engine type plate (example)

Please enter here:

Engine type (Fig. 1)

Engine number (2):

2.1 Technical data BW 80 AD-5

Dimensions




Fig. 3

A	B	C	D	H	H ₂	K	L	O	S	W
1483	856	433	580	1627	2304	255	2194	28	13	800
(58)	(34)	(17)	(23)	(64)	(91)	(10)	(86)	(1.1)	(0.5)	(32)

Dimensions in millimetre

(Dimensions in inch)

Weights		
Max. operating weight	1800	kg
	(3968)	(lbs)
Operating weight (CECE)	1550	kg
	(3417)	(lbs)

Technical data – Technical data BW 80 AD-5

Weights		
Mean axle load (CECE)	775 (1709)	kg (lbs)
Mean static linear load (CECE)	9.7 (54)	kg/cm (pli)

Travel characteristics		
Travel speed	0 - 10 (0 - 6.2)	km/h (mph)
Working speed with vibration	0 - 10 (0 - 6.2)	km/h (mph)
Max. gradability without/with vibration (soil dependent)	40/30	%

Drive		
Engine manufacturer	Kubota	
Type	D902	
Cooling	Water	
Number of cylinders	3	
Rated power ISO 14396	15.1	kW
Rated power SAE J 1995	20.2	hp
Rated speed	3000	min ⁻¹
Fixed engine speed (1)	2100	min ⁻¹
Fixed engine speed (2)	3000	min ⁻¹
Driven drum	front + rear	

Electric system		
Voltage	12	V

Technical data – Technical data BW 80 AD-5

Brakes		
Service brake	hydrostatic	
Parking brake	hydro-mechanical	

Steering		
Type of steering	Oscill.-articul.	
Steering operation	hydrostatic	
Steering angle	+/- 33	°
Oscillation angle	+/- 8	°
Inner track radius	2080 (81.9)	mm (in)
Crabwalk, lateral offsetting of drum right/left	0 - 50 (0 - 2.0)	mm (in)

Exciter system		
Vibrating drum	front + rear	
Drive system	hydrostatic	
Frequency (1/2)	42/63 (2520/3780)	Hz (vpm)
Amplitude	0.50 (0,020)	mm (in)
Centrifugal force (1/2)	8/17 (1798/3822)	kN (lbf)

Water sprinkler system		
Type of sprinkling	Pressure	

Filling capacities		
Fuel (diesel)	30 (7.9)	l (gal us)
Water	100 (26.4)	l (gal us)

2.1.1 Noise and vibration data

The following noise and vibration data were determined in accordance with the following guidelines under equipment specific conditions and by using harmonized standards:

- EU Machine Directive edition 2006/42/EU
- Noise Emission Directive 2000/14/EU, Noise Protection Directive 2003/10/EU
- Vibration Protection Directive 2002/44/EU

During operation these values may vary because of the prevailing operating conditions.

2.1.1.1 Noise data

Sound pressure level at the operator's stand

$L_{pA} = 84$ dB(A), determined acc. to ISO 11201 and EN 500.



WARNING!

Loss of hearing caused by too high noise burdens!

- Wear your personal protective equipment (ear protection).

Guaranteed sound power level

$L_{WA} = 100$ dB(A), determined acc. to ISO 3744 and EN 500

2.1.1.2 Vibration data

Vibration of the entire body (driver's seat)

The weighted effective acceleration value determined according to ISO 7096 is $\leq 0.5 \text{ m/s}^2$.

Hand-arm vibration

The weighted effective acceleration value determined according to EN 500/ISO 5349 is $\leq 2.5 \text{ m/s}^2$.

2.2 Technical data BW 90 AD-5

Dimensions




Fig. 4

A	B	C	D	H	H ₂	K	L	O	S	W
1483	956	433	580	1627	2304	255	2194	28	12	900
(58)	(38)	(17)	(23)	(64)	(91)	(10)	(86)	(1.1)	(0.5)	(35)
Dimensions in millimetre (Dimensions in inch)										

Weights		
Max. operating weight	2000	kg
	(4409)	(lbs)
Operating weight (CECE)	1600	kg
	(3527)	(lbs)

Technical data – Technical data BW 90 AD-5

Weights		
Mean axle load (CECE)	800 (1764)	kg (lbs)
Mean static linear load (CECE)	8.9 (50)	kg/cm (pli)

Travel characteristics		
Travel speed	0 - 10 (0 - 6.2)	km/h (mph)
Working speed with vibration	0 - 10 (0 - 6.2)	km/h (mph)
Max. gradability without/with vibration (soil dependent)	40/30	%

Drive		
Engine manufacturer	Kubota	
Type	D902	
Cooling	Water	
Number of cylinders	3	
Rated power ISO 14396	15.1	kW
Rated power SAE J 1995	20.2	hp
Rated speed	3000	min ⁻¹
Fixed engine speed (1)	2100	min ⁻¹
Fixed engine speed (2)	3000	min ⁻¹
Driven drum	front + rear	

Electric system		
Voltage	12	V

Technical data – Technical data BW 90 AD-5

Brakes		
Service brake	hydrostatic	
Parking brake	hydro-mechanical	

Steering		
Type of steering	Oscill.-articul.	
Steering operation	hydrostatic	
Steering angle	+/- 33	°
Oscillation angle	+/- 8	°
Inner track radius	2030 (79.9)	mm (in)
Crabwalk, lateral offsetting of drum right/left	0 - 50 (0 - 2.0)	mm (in)

Exciter system		
Vibrating drum	front + rear	
Drive system	hydrostatic	
Frequency (1/2)	42/63 (2520/3780)	Hz (vpm)
Amplitude	0.50 (0,020)	mm (in)
Centrifugal force (1/2)	8/17 (1798/3822)	kN (lbf)

Water sprinkler system		
Type of sprinkling	Pressure	

Filling capacities		
Fuel (diesel)	30 (7.9)	l (gal us)
Water	100 (26.4)	l (gal us)

2.2.1 Noise and vibration data

The following noise and vibration data were determined in accordance with the following guidelines under equipment specific conditions and by using harmonized standards:

- EU Machine Directive edition 2006/42/EU
- Noise Emission Directive 2000/14/EU, Noise Protection Directive 2003/10/EU
- Vibration Protection Directive 2002/44/EU

During operation these values may vary because of the prevailing operating conditions.

2.2.1.1 Noise data

Sound pressure level at the operator's stand

L_{pA} = 83 dB(A), determined acc. to ISO 11201 and EN 500.



WARNING!

Loss of hearing caused by too high noise burdens!

- Wear your personal protective equipment (ear protection).

Guaranteed sound power level

L_{WA} = 100 dB(A), determined acc. to ISO 3744 and EN 500

2.2.1.2 Vibration data

Vibration of the entire body (driver's seat)

The weighted effective acceleration value determined according to ISO 7096 is $\leq 0.5 \text{ m/s}^2$.

Hand-arm vibration

The weighted effective acceleration value determined according to EN 500/ISO 5349 is $\leq 2.5 \text{ m/s}^2$.

2.3 Technical data BW 100 ADM-5

Dimensions




Fig. 5

A	B	C	D	H	H ₂	K	L	O	S	W
1483	1056	433	580	1627	2304	255	2194	28	12	1000
(58)	(42)	(17)	(23)	(64)	(91)	(10)	(86)	(1.1)	(0.5)	(39)
Dimensions in millimetre (Dimensions in inch)										

Weights		
Max. operating weight	2000	kg
	(4409)	(lbs)
Operating weight (CECE)	1650	kg
	(3638)	(lbs)

Technical data – Technical data BW 100 ADM-5

Weights		
Mean axle load (CECE)	825 (1819)	kg (lbs)
Mean static linear load (CECE)	8.3 (46)	kg/cm (pli)

Travel characteristics		
Travel speed	0 - 10 (0 - 6.2)	km/h (mph)
Working speed with vibration	0 - 10 (0 - 6.2)	km/h (mph)
Max. gradability without/with vibration (soil dependent)	40/30	%

Drive		
Engine manufacturer	Kubota	
Type	D902	
Cooling	Water	
Number of cylinders	3	
Rated power ISO 14396	15.1	kW
Rated power SAE J 1995	20.2	hp
Rated speed	3000	min ⁻¹
Fixed engine speed (1)	2100	min ⁻¹
Fixed engine speed (2)	3000	min ⁻¹
Driven drum	front + rear	

Electric system		
Voltage	12	V

Technical data – Technical data BW 100 ADM-5

Brakes		
Service brake	hydrostatic	
Parking brake	hydro-mechanical	

Steering		
Type of steering	Oscill.-articul.	
Steering operation	hydrostatic	
Steering angle	+/- 33	°
Oscillation angle	+/- 8	°
Inner track radius	1980 (78.0)	mm (in)
Crabwalk, lateral offsetting of drum right/left	0 - 50 (0 - 2.0)	mm (in)

Exciter system		
Vibrating drum	front + rear	
Drive system	hydrostatic	
Frequency (1/2)	42/63 (2520/3780)	Hz (vpm)
Amplitude	0.40 (0,016)	mm (in)
Centrifugal force (1/2)	8/17 (1798/3822)	kN (lbf)

Water sprinkler system		
Type of sprinkling	Pressure	

Filling capacities		
Fuel (diesel)	30 (7.9)	l (gal us)
Water	100 (26.4)	l (gal us)

2.3.1 Noise and vibration data

The following noise and vibration data were determined in accordance with the following guidelines under equipment specific conditions and by using harmonized standards:

- EU Machine Directive edition 2006/42/EU
- Noise Emission Directive 2000/14/EU, Noise Protection Directive 2003/10/EU
- Vibration Protection Directive 2002/44/EU

During operation these values may vary because of the prevailing operating conditions.

2.3.1.1 Noise data

Sound pressure level at the operator's stand

$L_{pA} = 84 \text{ dB(A)}$, determined acc. to ISO 11201 and EN 500.



WARNING!

Loss of hearing caused by too high noise burdens!

- Wear your personal protective equipment (ear protection).

Guaranteed sound power level

$L_{WA} = 99 \text{ dB(A)}$, determined acc. to ISO 3744 and EN 500

2.3.1.2 Vibration data

Vibration of the entire body (driver's seat)

The weighted effective acceleration value determined according to ISO 7096 is $\leq 0.5 \text{ m/s}^2$.

Hand-arm vibration

The weighted effective acceleration value determined according to EN 500/ISO 5349 is $\leq 2.5 \text{ m/s}^2$.

2.4 Technical data BW 90 SC-5

Dimensions




Fig. 6

A	B	C	D	H	H ₂	K	L	O	S	W
1483	960	435	580	1627	2304	255	2194	52	12	960
(58)	(38)	(17)	(23)	(64)	(91)	(10)	(86)	(2.0)	(0.5)	(38)
Dimensions in millimetre (Dimensions in inch)										

Weights		
Max. operating weight	2000	kg
	(4409)	(lbs)
Operating weight (CECE)	1650	kg
	(3638)	(lbs)

Technical data – Technical data BW 90 SC-5

Weights		
Mean axle load (CECE)	825 (1819)	kg (lbs)
Mean static linear load (CECE)	9.2 (52)	kg/cm (pli)

Travel characteristics		
Travel speed	0 - 10 (0 - 6.2)	km/h (mph)
Working speed with vibration	0 - 10 (0 - 6.2)	km/h (mph)
Max. gradability without/with vibration (soil dependent)	40/30	%

Drive		
Engine manufacturer	Kubota	
Type	D902	
Cooling	Water	
Number of cylinders	3	
Rated power ISO 14396	15.1	kW
Rated power SAE J 1995	20.2	hp
Rated speed	3000	min ⁻¹
Fixed engine speed (1)	2100	min ⁻¹
Fixed engine speed (2)	3000	min ⁻¹
Driven drum	front + rear	

Electric system		
Voltage	12	V

Technical data – Technical data BW 90 SC-5

Brakes		
Service brake	hydrostatic	
Parking brake	hydro-mechanical	

Steering		
Type of steering	Oscill.-articul.	
Steering operation	hydrostatic	
Steering angle	+/- 33	°
Oscillation angle	+/- 8	°
Inner track radius	2000 (78.7)	mm (in)
Crabwalk, lateral offsetting of drum right/left	0 - 50 (0 - 2.0)	mm (in)

Exciter system		
Vibrating drum	front + rear	
Drive system	hydrostatic	
Frequency (1/2)	42/63 (2520/3780)	Hz (vpm)
Amplitude	0.50 (0,020)	mm (in)
Centrifugal force (1/2)	8/19 (1798/4271)	kN (lbf)

Water sprinkler system		
Type of sprinkling	Pressure	

Filling capacities		
Fuel (diesel)	30 (7.9)	l (gal us)
Water	100 (26.4)	l (gal us)

2.4.1 Noise and vibration data

The following noise and vibration data were determined in accordance with the following guidelines under equipment specific conditions and by using harmonized standards:

- EU Machine Directive edition 2006/42/EU
- Noise Emission Directive 2000/14/EU, Noise Protection Directive 2003/10/EU
- Vibration Protection Directive 2002/44/EU

During operation these values may vary because of the prevailing operating conditions.

2.4.1.1 Noise data

Sound pressure level at the operator's stand

$L_{pA} = 84$ dB(A), determined acc. to ISO 11201 and EN 500.



WARNING!

Loss of hearing caused by too high noise burdens!

- Wear your personal protective equipment (ear protection).

Guaranteed sound power level

$L_{WA} = 101$ dB(A), determined acc. to ISO 3744 and EN 500

2.4.1.2 Vibration data

Vibration of the entire body (driver's seat)

The weighted effective acceleration value determined according to ISO 7096 is $\leq 0.5 \text{ m/s}^2$.

Hand-arm vibration

The weighted effective acceleration value determined according to EN 500/ISO 5349 is $\leq 2.5 \text{ m/s}^2$.

2.5 Technical data BW 100 SC-5

Dimensions




Fig. 7

A	B	C	D	H	H ₂	K	L	O	S	W
1483	1060	435	580	1627	2304	255	2194	52	12	1060
(58)	(42)	(17)	(23)	(64)	(91)	(10)	(86)	(2.0)	(0.5)	(42)
Dimensions in millimetre (Dimensions in inch)										

Weights		
Max. operating weight	2000	kg
	(4409)	(lbs)
Operating weight (CECE)	1700	kg
	(3748)	(lbs)

Technical data – Technical data BW 100 SC-5

Weights		
Mean axle load (CECE)	850 (1874)	kg (lbs)
Mean static linear load (CECE)	8.5 (48)	kg/cm (pli)

Travel characteristics		
Travel speed	0 - 10 (0 - 6.2)	km/h (mph)
Working speed with vibration	0 - 10 (0 - 6.2)	km/h (mph)
Max. gradability without/with vibration (soil dependent)	40/30	%

Drive		
Engine manufacturer	Kubota	
Type	D902	
Cooling	Water	
Number of cylinders	3	
Rated power ISO 14396	15.1	kW
Rated power SAE J 1995	20.2	hp
Rated speed	3000	min ⁻¹
Fixed engine speed (1)	2100	min ⁻¹
Fixed engine speed (2)	3000	min ⁻¹
Driven drum	front + rear	

Electric system		
Voltage	12	V

Technical data – Technical data BW 100 SC-5

Brakes		
Service brake	hydrostatic	
Parking brake	hydro-mechanical	

Steering		
Type of steering	Oscill.-articul.	
Steering operation	hydrostatic	
Steering angle	+/- 33	°
Oscillation angle	+/- 8	°
Inner track radius	1950 (76.8)	mm (in)
Crabwalk, lateral offsetting of drum right/left	0 - 50 (0 - 2.0)	mm (in)

Exciter system		
Vibrating drum	front + rear	
Drive system	hydrostatic	
Frequency (1/2)	42/63 (2520/3780)	Hz (vpm)
Amplitude	0.50 (0,020)	mm (in)
Centrifugal force (1/2)	8/19 (1798/4271)	kN (lbf)

Water sprinkler system		
Type of sprinkling	Pressure	

Filling capacities		
Fuel (diesel)	30 (7.9)	l (gal us)
Water	100 (26.4)	l (gal us)

2.5.1 Noise and vibration data

The following noise and vibration data were determined in accordance with the following guidelines under equipment specific conditions and by using harmonized standards:

- EU Machine Directive edition 2006/42/EU
- Noise Emission Directive 2000/14/EU, Noise Protection Directive 2003/10/EU
- Vibration Protection Directive 2002/44/EU

During operation these values may vary because of the prevailing operating conditions.

2.5.1.1 Noise data

Sound pressure level at the operator's stand

$L_{pA} = 84 \text{ dB(A)}$, determined acc. to ISO 11201 and EN 500.



WARNING!

Loss of hearing caused by too high noise burdens!

- Wear your personal protective equipment (ear protection).

Guaranteed sound power level

$L_{WA} = 105 \text{ dB(A)}$, determined acc. to ISO 3744 and EN 500

2.5.1.2 Vibration data

Vibration of the entire body (driver's seat)

The weighted effective acceleration value determined according to ISO 7096 is $\leq 0.5 \text{ m/s}^2$.

Hand-arm vibration

The weighted effective acceleration value determined according to EN 500/ISO 5349 is $\leq 2.5 \text{ m/s}^2$.

2.6 Technical data BW 100 ACM-5

Dimensions




Fig. 8

A	B	C	D	H	H ₂	K	L	O	S	W
1483	1056	435	580	1663	2340	240	2194	28	12	1000
(58)	(42)	(17)	(23)	(66)	(92)	(9.4)	(86)	(1.1)	(0.5)	(39)
Dimensions in millimetre (Dimensions in inch)										

Weights		
Max. operating weight	2000	kg
	(4409)	(lbs)
Operating weight (CECE)	1700	kg
	(3748)	(lbs)
Axle load, drum (CECE)	800	kg
	(1764)	(lbs)

Technical data – Technical data BW 100 ACM-5

Weights		
Static linear load front (CECE)	8.0 (45)	kg/cm (pli)
Axle load, wheels (CECE)	900 (1984)	kg (lbs)
Wheel load (CECE)	225 (496)	kg (lbs)

Travel characteristics		
Travel speed	0 - 10 (0 - 6.2)	km/h (mph)
Working speed with vibration	0 - 10 (0 - 6.2)	km/h (mph)
Max. gradability without/with vibration (soil dependent)	40/30	%

Drive		
Engine manufacturer	Kubota	
Type	D902	
Cooling	Water	
Number of cylinders	3	
Rated power ISO 14396	15.1	kW
Rated power SAE J 1995	20.2	hp
Rated speed	3000	min ⁻¹
Fixed engine speed (1)	2100	min ⁻¹
Fixed engine speed (2)	3000	min ⁻¹
Driven drum	front	
Wheels driven	4	

Technical data – Technical data BW 100 ACM-5

Electric system		
Voltage	12	V

Tires		
Tire size	205/60-15	

Brakes		
Service brake	hydrostatic	
Parking brake	hydro-mechanical	

Steering		
Type of steering	Oscill.-articul.	
Steering operation	hydrostatic	
Steering angle	+/- 33	°
Oscillation angle	+/- 8	°
Inner track radius	1980 (78.0)	mm (in)
Crabwalk, lateral offsetting of drum right/left	0 - 50 (0 - 2.0)	mm (in)

Exciter system		
Vibrating drum	front	
Drive system	hydrostatic	
Frequency (1/2)	42/63 (2520/3780)	Hz (vpm)
Amplitude	0.40 (0,016)	mm (in)
Centrifugal force (1/2)	8/17 (1798/3822)	kN (lbf)

Technical data – Technical data BW 100 ACM-5

Water sprinkler system		
Type of sprinkling	Pressure	

Filling capacities		
Fuel (diesel)	30 (7.9)	l (gal us)
Water	100 (26.4)	l (gal us)
Emulsion	11 (2.9)	l (gal us)

2.6.1 Noise and vibration data

The following noise and vibration data were determined in accordance with the following guidelines under equipment specific conditions and by using harmonized standards:

- EU Machine Directive edition 2006/42/EU
- Noise Emission Directive 2000/14/EU, Noise Protection Directive 2003/10/EU
- Vibration Protection Directive 2002/44/EU

During operation these values may vary because of the prevailing operating conditions.

2.6.1.1 Noise data

Sound pressure level at the operator's stand

$L_{pA} = 83 \text{ dB(A)}$, determined acc. to ISO 11201 and EN 500.



WARNING!

Loss of hearing caused by too high noise burdens!

- Wear your personal protective equipment (ear protection).

Guaranteed sound power level

$L_{WA} = 100 \text{ dB(A)}$, determined acc. to ISO 3744 and EN 500

2.6.1.2 Vibration data

Vibration of the entire body (driver's seat)

The weighted effective acceleration value determined according to ISO 7096 is $\leq 0.5 \text{ m/s}^2$.

Hand-arm vibration

The weighted effective acceleration value determined according to EN 500/ISO 5349 is $\leq 2.5 \text{ m/s}^2$.

2.7 Technical data BW 100 SCC-5

Dimensions




Fig. 9

A	B	C	D	H	H ₂	K	L	O	S	W
1483	1056	435	580	1663	2340	240	2194	28	12	1000
(58)	(42)	(17)	(23)	(66)	(92)	(9.4)	(86)	(1.1)	(0.5)	(39)
Dimensions in millimetre (Dimensions in inch)										

Weights		
Max. operating weight	2000	kg
	(4409)	(lbs)
Operating weight (CECE)	1700	kg
	(3748)	(lbs)
Axle load, drum (CECE)	800	kg
	(1764)	(lbs)

Technical data – Technical data BW 100 SCC-5

Weights		
Static linear load front (CECE)	8.0 (45)	kg/cm (pli)
Axle load, wheels (CECE)	900 (1984)	kg (lbs)
Wheel load (CECE)	225 (496)	kg (lbs)

Travel characteristics		
Travel speed	0 - 10 (0 - 6.2)	km/h (mph)
Working speed with vibration	0 - 10 (0 - 6.2)	km/h (mph)
Max. gradability without/with vibration (soil dependent)	40/30	%

Drive		
Engine manufacturer	Kubota	
Type	D902	
Cooling	Water	
Number of cylinders	3	
Rated power ISO 14396	15.1	kW
Rated power SAE J 1995	20.2	hp
Rated speed	3000	min ⁻¹
Fixed engine speed (1)	2100	min ⁻¹
Fixed engine speed (2)	3000	min ⁻¹
Driven drum	front	
Wheels driven	4	

Technical data – Technical data BW 100 SCC-5

Electric system		
Voltage	12	V

Tires		
Tire size	205/60-15	

Brakes		
Service brake	hydrostatic	
Parking brake	hydro-mechanical	

Steering		
Type of steering	Oscill.-articul.	
Steering operation	hydrostatic	
Steering angle	+/- 33	°
Oscillation angle	+/- 8	°
Inner track radius	1980 (78.0)	mm (in)
Crabwalk, lateral offsetting of drum right/left	0 - 50 (0 - 2.0)	mm (in)

Exciter system		
Vibrating drum	front	
Drive system	hydrostatic	
Frequency (1/2)	42/63 (2520/3780)	Hz (vpm)
Amplitude	0.40 (0,016)	mm (in)
Centrifugal force (1/2)	8/19 (1798/4271)	kN (lbf)

Water sprinkler system		
Type of sprinkling	Pressure	

Filling capacities		
Fuel (diesel)	30 (7.9)	l (gal us)
Water	100 (26.4)	l (gal us)
Emulsion	11 (2.9)	l (gal us)

2.7.1 Noise and vibration data

The following noise and vibration data were determined in accordance with the following guidelines under equipment specific conditions and by using harmonized standards:

- EU Machine Directive edition 2006/42/EU
- Noise Emission Directive 2000/14/EU, Noise Protection Directive 2003/10/EU
- Vibration Protection Directive 2002/44/EU

During operation these values may vary because of the prevailing operating conditions.

2.7.1.1 Noise data

Sound pressure level at the operator's stand

$L_{pA} = 84 \text{ dB(A)}$, determined acc. to ISO 11201 and EN 500.



WARNING!

Loss of hearing caused by too high noise burdens!

- Wear your personal protective equipment (ear protection).

Guaranteed sound power level

$L_{WA} = 100 \text{ dB(A)}$, determined acc. to ISO 3744 and EN 500

2.7.1.2 Vibration data

Vibration of the entire body (driver's seat)

The weighted effective acceleration value determined according to ISO 7096 is $\leq 0.5 \text{ m/s}^2$.

Hand-arm vibration

The weighted effective acceleration value determined according to EN 500/ISO 5349 is $\leq 2.5 \text{ m/s}^2$.

General

This BOMAG machine has been built in compliance with the latest technical standard and complies with the applicable regulations and technical rules. However, dangers for persons and property may arise from this machine, if:

- it is used for purposes other than the ones it is intended for,
- it is operated by untrained personnel,
- it is changed or converted in an unprofessional way,
- the safety instructions are not observed.

Each person involved in the operation, maintenance and repair of the machine must therefore read and comply with these safety regulations. If necessary, this must be confirmed by obtaining the signature of the customer.

Furthermore, the following obviously also applies:

- applicable accident prevention instructions,
- generally accepted safety and road traffic regulations,
- country specific safety regulations. It is the duty of the operator to be acquainted with these instructions and to apply these accordingly. This applies also for local regulations concerning different types of handling work. Should the recommendations in these instructions be different from the regulations valid in your country, you must comply with the safety regulations valid in your country.

Intended use

This machine must only be used for:

- Compaction of bituminous material, e.g. road surface layers,
- light to medium compaction work in earth construction or road sub-bases.

Improper use

Dangers may arise from the machine when it is used for purposes other than the one it is intended for.

Any danger caused by improper use is the sole responsibility of the operating company or driver/operator, the manufacturer cannot be made liable.

Examples for improper use are:

- work with vibration on hard concrete, cured bitumen layers or extremely frozen ground
- cleaning the drums while driving or changing nozzles during travel.
- driving on subsoils with too low load bearing capacity
- driving on slippery subsoils (e.g. ice and snow)
- driving on surfaces of insufficient size (danger of turning over)
- Passing over too high borders (e.g. curb-stones, embankments, trenches, potholes)
- unauthorized use of public roads
- Using the machine for towing

transporting persons, except the machine driver, is prohibited.

starting and operation of the machine in explosive environments and in underground mining is prohibited.

Remaining dangers, remaining risks

Despite careful work and compliance with standards and regulations it cannot be ruled out that further dangers may arise when working with and handling the machine.

Safety regulations

Both the machine as well as all other system components comply with the currently valid safety regulations. Nevertheless, remaining risks cannot be ruled out completely, even when using the machine for the purpose it is intended for and following all information given in the operating instructions.

A remaining risk can also not be excluded beyond the actual danger zone of the machine. Persons remaining in this area must pay particular attention to the machine, so that they can react immediately in case of a possible malfunction, an incident or failure etc.

All persons remaining in the area of the machine must be informed about the dangers that arise from the operation of the machine.

Regular safety inspections

Have the machine inspected by an expert (capable person) as required for the condition the machine is working under, but at least once every year.

Who is allowed to operate the machine?

Only trained, instructed and authorized persons of at least 18 years of age are permitted to drive and operate this machine. For operation of the machine the responsibilities must be clearly specified and complied with.

Persons under the influence of alcohol, medicine or drugs are not allowed to operate, service or repair the machine.

Maintenance and repair work requires specific knowledge and must therefore only be performed by trained specialists.

Changes and conversions to the machine

Unauthorized changes to the machine are prohibited for safety reasons.

Original parts and accessories have been specially designed for this machine.

We wish to make explicitly clear that we have not tested or approved any parts or accessories not supplied by us.

The installation and/or use of such products may have an adverse effect on the active and/or passive safety.

The manufacturer explicitly excludes any liability for damage caused by the use of non-original parts or accessories.

Damage, deficiencies, misuse of safety installations

Machines which are not safe to operate or in traffic must be immediately taken out of service and shall not be used, until these deficiencies have been properly rectified.

Safety installations and switches must neither be removed nor must they be made ineffective.

Notes on safety in the operating and maintenance instructions



WARNING!

Paragraphs marked like this highlight possible dangers for persons.



NOTICE!

Paragraphs marked like this highlight possible dangers for machines or parts of the machine.



Paragraphs marked like this contain technical information for the optimal economical use of the machine.



ENVIRONMENT!

Paragraphs marked like this point out practices for safe and environmental disposal of fuels and lubricants as well as replacement parts.

Observe the regulations for the protection of the environment.

Loading / transporting the machine

Loading with loading ramp

Use only stable loading ramps of sufficient load bearing capacity. The ramp inclination must be less than the gradability of the machine.

The ramp must be free of grease, oil, snow and ice.

Make sure that persons are not endangered by the machine tipping or sliding off.

During demonstration and when loading the machine do not remain in the danger zone of the machine.

Secure the machine with the articulation lock after driving it on the transport vehicle.

Loading by crane

Lifting tackle must only be attached to loads by expert personnel (qualified person).

Engage the articulation lock.

Always use suitable lifting tackle on the lifting points to lift the machine.

Check all lifting points and fastening elements for damage before lifting the machine. Do not use damaged or in any other way impaired lifting points.

Lift the machine only with suitable lifting gear. Use only safe lifting gear of sufficient load bearing capacity. Minimum lifting capacity of lifting gear: see operating weight in chapter "Technical Data".

Do not lift or lower the machine jerkily.

The tension must always be effective in vertical direction.

The machine must not swing about when being lifted.

Do not step or stand under suspended loads.

Lashing

Always use suitable lashing gear on the lifting points to lash down the machine.

Check all lashing points for damage before lashing down the machine. Do not use a damaged or in any other way impaired lashing points.

Always apply the articulation lock for transportation.

Lash the machine down, so that it is secured against rolling, sliding and turning over.

After transport

Operate the machine only with the foldable ROPS properly fastened and the fastening screws tightened with the correct tightening torque. Optional equipment

After transport release the articulation lock again and store it in the receptacle.

Towing the machine

Apply appropriate measures (e.g. with metal wheel chocks, to be provided by the operating company) to secure the machine against rolling away before releasing the parking brake.

Use a tow bar (to be provided by the operating company).

Safety regulations

Use a towing vehicle with sufficient traction and braking power for the unbraked towed load.

The machine cannot be steered.

Tow the machine only after having released the parking brake.

Max. towing speed 1 km/h (0.6 mph), max.
towing distance 500 m (0.3 mi).

Checking the Roll Over Protective Structure (ROPS)

The frame of the machine must not be warped, bent or cracked in the area of the ROPS fastening.

The ROPS must not show any rust, damage, hairline cracks or open fractures.

The real machine weight must never exceed the testing weight for the ROPS.

The ROPS must not rattle about when driving. This indicates that it is not properly fastened. All bolted connections must comply with the specifications and should be absolutely tight (observe the tightening torques). Screw and nuts must not be damaged, bent or deformed.

No accessories may be welded or bolted on and no additional holes must be drilled without the consent of the manufacturer, since this will impair the strength of the unit.

The ROPS must therefore also not be straightened or repaired if it is damaged.

A defect ROPS must generally be replaced with an original spare part in close coordination with the manufacturer.

Starting the machine

Before starting

Use only machines which are serviced at regular intervals.

Become acquainted with the equipment, the control elements, the working principle of the machine and the working area.

Wear your personal protective outfit (hard hat, safety boots, etc.). Wear ear defenders.

Before mounting the machine check whether:

- persons or obstructions are beside or under the machine.
- the machine is free of oily and combustible material.
- all grips, steps and platforms are free of grease, oils, fuel, dirt, snow and ice.
- the engine hood is closed and locked.

Use steps and grips to mount the machine.

Before starting the machine check whether:

- the machine shows any obvious faults.
- all guards and safety elements are in place.
- steering, brakes, control elements, light system and warning horn work correctly.
- the seat is correctly adjusted
- mirrors (if present) are clean and correctly adjusted.

Do not start the machine with defective gauges, control lights or control elements.

Do not take any loose objects with you or fasten them to the machine.

On machines with roll over protection system you must always wear your seat belt!

Starting

Start and operate the machine only from the driver's seat.

For starting set all control levers to 'neutral position'.

Do not use any starting aids like start pilot or ether.

After starting check all display instruments.

Starting with jump wires

Connect plus to plus and minus to minus (ground cable) – always connect the ground strap last and disconnect it first! A wrong connection will cause severe damage in the electric system.

Do not start the engine by shorting the electric terminals on the starter motor, because the machine may start to drive immediately.

Starting and operation of the machine is closed rooms and trenches

Exhaust gases are extremely dangerous! Always ensure an adequate supply of fresh air when starting and operating in closed rooms and trenches!

Driving the machine

Persons in the danger area

Before taking up work, also after breaks, you should always convince yourself that the danger zone is free of persons or obstructions, especially when driving in reverse.

Give warning signals, if necessary. Stop work immediately if persons remain in the danger zone, despite the warning.

Do not step or stand in the articulation area of the machine when the engine is running.
Danger of squashing!

Driving

Always wear the seat belt when driving.

Do not drive on bases with insufficient load bearing capacity.

Do not drive on ice and snow.

In events of emergency and in case of danger actuate the emergency stop switch immediately. Do not use the emergency stop switch as service brake.

Restart the machine only after the danger that caused the actuation of the emergency stop switch has been eliminated.

Do not drive the machine with the hydraulic breaker connected. Optional equipment

Do not switch on the rotary switch for hydraulic breaker¹ while driving. The machine would be abruptly braked without braking delay. In case of frequent use the wear on the multi-discs brakes will be very high.

If the machine has contacted high-voltage power lines:

- do not leave the operator's stand.
- warn others from coming close to or touching the machine.
- if possible drive the machine out of the danger zone.
- have the power switched off.

Operate the machine only from the driver's seat.

Do not adjust the driver's seat while driving.

Do not climb onto or off the machine while the machine is driving.

Change the travel direction only at standstill.

Do not use the machine to transport persons.

In case of unusual noises and development of smoke perform trouble shooting and have the fault corrected.

Always keep a sufficient distance to excavation walls and embankments and do not use working methods that could impair the stability of the machine.

Always keep a sufficient distance when passing through subways, under bridges, tunnels, electric power lines etc.

Driving on inclinations and slopes

Do not drive on gradients exceeding the maximum gradability of the machine.

On slopes drive extremely careful and always directly up or down the slope. Change to a lower gear before starting to drive.

Wet and loose soils considerably reduce the ground adhesion of the machine on inclinations and slopes. Higher risk of accident!

Inclination




Fig. 10

The tipping angle was measured in static condition on level, hard ground with the machine stopped, no steering and without vibration.

The maximum permissible inclination of the machine may be limited by the permissible inclination of the engine.

The specified angle ↗ Fig. 10 must not be exceeded.

With loose soil, acceleration/deceleration, running vibration, steering or attached accessories the tipping angle may be considerably lower.

Driving across slopes should therefore be strictly avoided, because of the high risk of tipping over and the related risk of severe or even fatal accidents.

You should therefore always drive straight up or down a slope.

For rollers with a drum width of 1 m (3.3 ft) or less there is a considerable risk of tipping over near edges (e.g. curbstones, embankments, trenches, potholes) when driving over these edges.

Behaviour in traffic

Match the speed to the working conditions. Do not make extreme steering movements when driving with high speed, danger of tipping over!

Always give way to loaded transport vehicles.

Switch the lights on if the visibility is poor.

Keep away from edges and embankments.

Checking the effect of vibration

When compacting with vibration you must check the effect on nearby buildings and underground supply lines (gas, water, sewage, electric power), if necessary stop compaction work with vibration.

Do not work with vibration on hard concrete, cured bitumen layers or extremely frozen ground. Danger of bearing damage!

Parking the machine

Park the machine on horizontal, level, firm ground.

Before leaving the machine:

Safety regulations

- Shift the travel lever to neutral position and lock it in parking brake position. The parking brake is applied.
- Shut down the engine, pull off the ignition key

Mark machines, which could be in the way, with a clearly visible sign.

Parking on slopes and inclinations

Apply appropriate measures (e.g. with metal wheel chocks, to be provided by the operating company) to secure the machine against rolling away.

Refuelling

Do not inhale any fuel fumes.

Refuel only with the engine shut down.

Always use access steps.

Do not refuel in closed rooms.

No open fire, do not smoke.

Static charges may be generated in the fuel as it passes through the filling system. A discharge of such charges in the presence of combustible vapours may cause fire or an explosion.

Ultra-low sulphur diesel fuel poses a higher risk of ignition caused by static charges than a diesel fuel with a higher sulphur content.

You should therefore always make sure that the filling system is properly earthed and that there is equipotential bonding to the machine. If necessary install a connecting cable between filling system and vehicle ground.

Monitor the entire refuelling process.

Do not spill any fuel. Catch running out fuel, do not let it seep into the ground.

Wipe off spilled fuel. Keep dirt and water away from the fuel.

A leaking fuel tank can cause an explosion. Ensure tight fit of the fuel tank cover, if necessary replace immediately.

Fire protection measures

Familiarise yourself with the location and the operation of fire fighting equipment. Observe all fire reporting and fire fighting possibilities.

Maintenance work

Comply with the maintenance work described in the operating and maintenance instructions, including the information concerning the replacement of parts.

Maintenance work must only be performed by qualified and authorized persons.

Do not touch hot engine parts.

For overhead maintenance and assembly work use the access steps and working platforms provided or other secure means. Do not use machine parts as access steps.

Keep unauthorized persons away from the machine.

Do not perform maintenance work while the machine is driving or the engine is running.

Park the machine on horizontal, level, firm ground.

Remove the key from the ignition switch.

Secure the articulated joint with the articulation lock.

Work on hydraulic lines

Relieve hydraulic pressures before working on hydraulic lines. Hydraulic oil escaping under pressure can penetrate the skin and cause severe injury. When being injured by hydraulic oil consult a medical doctor immediately, as otherwise this may cause severe infections.

Do not step in front of or behind the drums/wheels when performing adjustment work in the hydraulic system.

Do not change the setting of pressure relief valves.

Drain the hydraulic oil at operating temperature – danger of scalding!

Any hydraulic oil must be caught and disposed of in an environmentally friendly manner.

Always catch and dispose of hydraulic oils separately.

Do not start the engine after draining the hydraulic oil.

Once all work is completed (with the system still depressurized!) check all connections and fittings for leaks.

Changing hydraulic hoses

Hydraulic hoses must be visually inspected at regular intervals.

Hydraulic hoses must be immediately replaced if:

- the outer layer is damaged down to the inlay (e.g. chafing, cuts, cracks).
- the outer layer is brittle (formation of cracks in the hose material).
- the hose shows deformations in pressurized and depressurized condition, which do not comply with the genuine shape of the hydraulic hose.
- the hose shows deformations in bends, e.g. squeezing, buckling, layer separation, formation of blisters,
- parts of the hose are leaking.
- hoses are not correctly installed
- the hydraulic hose has separated from the fitting

- the fitting shows corrosion that impairs both function and strength.
- fittings are damaged or deformed, whereby the function and strength of the hose - hose connection is impaired.

hoses are mixed up by mistake.

Only genuine BOMAG replacement hydraulic hoses ensure that the correct hose type (pressure range) is used at the right location.

Working on the engine

Shut down the engine before opening the engine hood.

Drain the engine oil at operating temperature – danger of scalding!

Wipe off spilled oil, catch running out oil and dispose of environmentally.

Store used filters and other oil contaminated materials in a separate, specially marked container and dispose of environmentally.

Do not leave any tools or other objects, that could cause damage, in the engine compartment.

Check and change coolant only when the engine is cold.

Catch coolant and dispose of environmentally.

Working on electric parts of the machine

Before starting to work on electric parts of the machine disconnect the battery and cover it with insulating material.

Do not use fuses with higher ampere ratings and do not bridge fuses. Fire hazard!

Working on the battery

When working on the battery do not smoke, do not use open fire!

Safety regulations

Do not let acid come in contact with hands or clothes! When injured by acid flush off with clear water and seek medical advice.

Metal objects (e.g. tools, rings, watch straps) must not come in contact with the battery poles – danger of short circuit and burning!

When recharging non-serviceable batteries remove all plugs, to avoid the accumulation of explosive gases.

Observe the applicable instructions when starting with an auxiliary battery.

Switch off the charging current before removing the charging clamps.

Ensure sufficient ventilation, especially if the battery is to be charged in a closed room.

Dispose of old batteries according to regulations.

Working on the fuel system

Do not inhale any fuel fumes.

Avoid open fire, do not smoke, do not spill any fuel.

Catch running out fuel, do not let it seep into the ground and dispose off environmentally.

Working on wheels and tires

Explosion-like bursting of tires or parts of tires and rims can cause most severe or even deadly injuries.

Install the tires only if are sufficiently experienced and with the right tools at hand. If necessary have the tires assembled in a qualified workshop.

Always ensure the correct tire pressure and do not exceed the specified maximum pressure.

Check tires and wheels every day for pressure, cuts, bulges, damaged rims, missing wheel studs or nuts. Do not drive with damaged tires or wheels.

Ant-sticking emulsions for tires must only consist of water and anti-sticking agent, in a concentration in accordance with the specifications of the manufacturer of the anti-sticking agent. Observe applicable environmental regulations.

Cleaning work

Do not perform cleaning work while the motor is running.

Do not use gasoline or other easily inflammable substances for cleaning.

When cleaning with steam cleaning equipment do not subject electrical parts and insulation material to the direct jet of water, or cover it beforehand.

- Do not guide the water jet into the exhaust and into the air filter.

After maintenance work

After all maintenance work is completed reinstall all guards and safety installations.

Repair

Mark a defective machine by attaching a warning tag to the steering wheel.

Repair work must only be performed by qualified and authorized persons. Use our repair instructions for this work.

Exhaust gases are extremely dangerous!
Always ensure an adequate supply of fresh air when starting in closed rooms!

Disconnect the battery before starting welding work on the machine.

Safety regulations

Information and safety stickers/decals on the machine

Keep stickers/decals in good and legible condition (see spare parts catalogue) and comply with their meaning.

Replace damaged and illegible stickers/decals.





Fig. 11: Decals and stickers BW 80 AD-5 / BW 90 AD-5 / BW 100 ADM-5

- 1 Information sticker - Engine oil drain
- 2 Information sticker - Guaranteed sound capacity level
- 3 Information sticker - Lifting point
- 4 Information sticker - Battery

- 5 Operation sticker - Throttle lever
- 6 Warning sticker - Danger of tipping over
- 7 Prohibition sticker - High pressure cleaner
- 8 Information sticker - Lashing point
- 9 Warning sticker - Danger of crushing
- 10 Information sticker - Ultra-low sulphur fuel
- 11 Information sticker - Hydraulic oil




462163

Fig. 12: Decals and stickers BW 90 SC-5 / BW 100 SC-5

- 1 Information sticker - Engine oil drain
- 2 Information sticker - Guaranteed sound capacity level

Safety regulations

- 3 Information sticker - Lifting point
- 4 Information sticker - Battery
- 5 Operation sticker - Throttle lever
- 6 Warning sticker - Danger of tipping over
- 7 Prohibition sticker - High pressure cleaner
- 8 Warning sticker - Danger of crushing
- 9 Information sticker - Ultra-low sulphur fuel
- 10 Information sticker - Hydraulic oil
- 11 Information sticker - Lashing point




462162

Fig. 13: Stickers and decals BW 100 ACM-5

- 1 Information sticker - Engine oil drain
- 2 Information sticker - Battery
- 3 Information sticker - Guaranteed sound capacity level
- 4 Information sticker - Lifting point
- 5 Information sticker - Foot switch tire sprinkling system
- 6 Operation sticker - Throttle lever
- 7 Warning sticker - Danger of tipping over
- 8 Information sticker - Emulsion
- 9 Prohibition sticker - High pressure cleaner
- 10 Information sticker - Lashing point

Safety regulations

- 11 Warning sticker - Danger of crushing
- 12 Information sticker - Ultra-low sulphur fuel
- 13 Information sticker - Hydraulic oil



462160

Fig. 14: Stickers and decals BW 100 SCC-5


- 1 Information sticker - Engine oil drain
- 2 Information sticker - Battery
- 3 Information sticker - Guaranteed sound capacity level
- 4 Information sticker - Lifting point
- 5 Information sticker - Foot switch tire sprinkling system
- 6 Operation sticker - Throttle lever

- 7 Warning sticker - Danger of tipping over
- 8 Information sticker - Emulsion
- 9 Prohibition sticker - High pressure cleaner
- 10 Information sticker - Lashing point
- 11 Warning sticker - Danger of crushing
- 12 Information sticker - Ultra-low sulphur fuel
- 13 Information sticker - Hydraulic oil



Warning sticker - Follow operating instructions

Fig. 15



Information sticker - Foldable ROPS - Operation


Fig. 16



Warning sticker - Foldable ROPS

Fig. 17

Safety regulations




Instruction sticker - Always wear your seat belt

Fig. 18




Information sticker - Main battery switch

Fig. 19



Information sticker - Electronic immobilizer

Fig. 20



B-462-0001

Fig. 21

- 1 Rotary switch for working lights
- 2 Rotary switch for lighting (*optional equipment*)
- 3 Rotary switch for hazard light system (*optional equipment*)

- 4 Rotary switch for flashing beacon (*optional equipment*)
- 5 Rotary switch for vibration pre-selection
- 6 Rotary switch for vibration, drum pre-selection (*not on ACM/SCC machines*)
- 7 Interval switch for pressurized spraying system
- 8 Rotary switch for direction indicators (*optional equipment*)
- 9 Emergency stop switch
- 10 Rotary switch for seat heating (*optional equipment*)
- 11 Rotary switch for hydraulic breaker (*optional equipment*)
- 12 Economizer display (*optional equipment*)
- 13 Instrument cluster
- 14 Starter switch
- 15 12V socket
- 16 Travel lever
- 17 Double travel lever (*optional equipment*)
- 18 Throttle lever

4.1 General notes

If you are not yet familiar with the control and display elements on this machine you should read this section thoroughly before starting any operation on the machine. Here all functions are described in detail.

The section "Operation" contains only brief descriptions of the individual control steps.

4.2 Description of indicators and control elements



Fig. 22

■ Rotary switch for working lights

Position "Left"	Working lights off
Position "Right"	Working light on (with starter switch in position "I")




Fig. 23

■ Rotary switch for lighting^{Optional equipment}

Position "Left"	Light off
Position "middle"	Side light on (with starter switch in position "I")
Position "Right"	Travel light on (with starter switch in position "I")




Fig. 24

■ Rotary switch for hazard light system^{Optional equipment}

Position "Left"	Hazard light system off
Position "Right"	Hazard light system on All direction indicators, warning lights in switch and indicator control light in the instrument cluster start flashing.



Fig. 25

- Rotary switch for flashing beacon^{Optional equipment}

Position "Left"	Flashing beacon off
Position "Right"	Flashing beacon on




Fig. 26

- Rotary switch for vibration pre-selection

Position "Left"	Pre-selection vibration in manual mode Vibration is switched on or off via the vibration push button in the travel lever.
Position "Middle"	Vibration off
Position "Right"	Pre-selection vibration in automatic mode Vibration is automatically switched on or off when a certain travel speed is exceeded or fallen short of. The vibration push button in the travel lever is not active.




Fig. 27

- Rotary switch for vibration, drum pre-selection^{not on AC-machines}

i *Vibration change-over is only activated if the vibration is switched off beforehand.*

Position "Left"	Vibration of front drum
Position "middle"	Vibration of front and rear drums
Position "Right"	Vibration of rear drum




Fig. 28

■ Interval switch for pressure sprinkling system

Position "0"	Sprinkling off
Position "1" to "4"	various sprinkling intervals
Position "5"	Permanent sprinkling

i *With the travel lever in neutral position and interval switch in position "5" (permanent sprinkling) the sprinkling system is already active.*

With interval sprinkling the machine needs to drive forward or backward.

With the travel lever in neutral position sprinkling will continue for another 15 seconds.




Fig. 29

■ Rotary switch for direction indicators^{Optional equipment}

Position "Left"	Front and rear left direction indicators are flashing
Position "Middle"	Direction indicators off
Position "Right"	Front and rear right direction indicators are flashing




Fig. 30

■ Emergency stop push button



WARNING!
Danger of accident!
Use only in events of emergency during operation.
Do not use as parking brake.
Restart the machine only after the danger that caused the actuation of the emergency stop switch has been eliminated.
The machine is braked immediately, the engine is shut down.

i *The emergency stop switch is automatically actuated when the dashboard protection is closed.*

actuate	Press the button completely down, it automatically locks in fully pressed position.
switch off/unlock	Turn button clockwise. Restart the engine .




Fig. 31

■ Rotary switch for seat heating (*optional equipment*)

Position "Left"	Seat heating off
Position "Right"	Seat heating on




Fig. 32

■ Rotary switch for hydraulic breaker^{Optional equipment}



WARNING!

Danger of accident!

Do not drive the machine with the hydraulic breaker connected.

Do not switch on the rotary switch for hydraulic breaker while driving. The machine would be abruptly braked without braking delay.



NOTICE!

Once the rotary switch for the hydraulic breaker has been switched to the right, the hydraulic breaker is active. The parking brake is applied at the same time. The machine is no longer able to drive. Always keep the travel lever in parking brake position.

Position Left

Hydraulic breaker off

Position Right

Hydraulic breaker on,
parking brake applied




Fig. 33

■ Economizer display^{Optional equipment}

1 - 10 yellow	Measuring value display
a red	Measuring fault warning lamp

i Description see section "Operation - operating the Economizer"




Fig. 34

■ Start switch

Position "P"/"O"	Ignition off, key can be pulled out
Position "I"	Ignition on, all warning and control lights in the instrument cluster light up for a moment *test function(, the lighting szstem can be switched on.
Position "II"	Pre-heating position, at temperatures below +10 °C (+50 °F), hold the ignition key in position "II" for up to 10 seconds, the pre-heating control lamp in the instrument cluster lights.



The engine can only be started if the travel lever is in braking position and the emergency stop switch is unlocked.

The starter switch is designed with a re-start lock. The ignition key must first be turned back to position "0" before a new starting attempt can be made.

Position "III"


Turn further against spring pressure, the engine starts, turn the ignition key back to position "I" once the engine has started.



NOTICE!

Run the engine warm for a short while before starting work. Do not rev up a cold engine to high idle speed/full load speed.

Do not shut down the engine all of a sudden from full load speed, but let it idle for about 2 minutes.



■ 12V-socket

Permanent current, loadable up to 10 A.

Fig. 35




Fig. 36

■ Travel lever

Position "Middle"	Neutral position
Position "middle right"	Parking brake position, the parking brake is closed.
Position "I"	Forward/reverse travel up to approx. 5 km/h (3.1 mph)
Position "II"	Forward/reverse travel up to approx. 10 km/h (6.2 mph)




Fig. 37

a	Vibration on/off
b	Warning horn




Fig. 38

Button assignment with edge cutter

c	Edge cutter up
d	Edge cutter down




Fig. 39

■ Double travel lever^{Optional equipment}

Position "Middle"	Neutral position
Position "middle left"	Parking brake position, the parking brake is closed.
Position "I"	Forward/reverse travel up to approx. 5 km/h (3.1 mph)
Position "II"	Forward/reverse travel up to approx. 10 km/h (6.2 mph)




Fig. 40

a	Vibration on/off
b	Warning horn




Fig. 41

■ Throttle lever

Position "MIN"	Idle speed position
Position "MAX I"	Full load position I, operating position for driving and vibration
Position "MAX II"	Full load position II, operating position for driving and vibration




Fig. 42

■ Foo switch for emulsion sprinkling

press	Sprinkling on
release	Sprinkling off



Only on ACM/SCC-machines.




Fig. 43

■ Main battery switch

The main battery switch is located inside the battery compartment.

Position "Vertical"	Normal position, operation
Position "Horizontal"	Detachable, isolates batteries from the on-board electrics in case of cable fire and fire in the engine compartment as well as protection against unauthorized use.



Optional equipment






Fig. 44

■ Fuel level gauge



■ Water level gauge


Fig. 45



■ Hydraulic oil level gauge

Fig. 46

4.3 Instrument cluster



B-DIS-0516

Fig. 47

- 1 Control and warning lights
- 2 Fuel level gauge
- 3 Display field
- 4 Function key [F1] (not assigned)
- 5 Function key [F2]


Control and warning lights

	Designation	Note
	Driver's seat warning light	Lights up when the driver's seat is not occupied. If the machine is travelling, the warning buzzer will sound and the engine is shut down after 2 seconds. If the travel lever is shifted to any travel direction, the engine is shut down. If the engine stops, occupy the driver's seat and restart the engine.
	Pre-heating control light	Lights up during pre-heating.

Indicators and control elements – Instrument cluster

	Designation	Note
	Engine oil pressure warning light	Lights up if the engine oil pressure is too low. Warning buzzer sounds. The engine is shut down after a short while. Check the engine oil level, if necessary, repair the engine.
	Warning light for overheating of engine	Lights up when the engine overheats. Warning buzzer sounds. The engine is shut down after 2 seconds. Run the engine with idle speed or, if necessary, shut it down and clean the radiator, if necessary, repair the engine.
	Charge control light	Lights up if the battery is not being charged. Check V-belt, if necessary repair the generator.
	Indicator control light	
	Parking brake warning light	Lights up when the parking brake is applied.
	Central warning light	Flashes in case of a fault of the rotation angle sensor or rotary switch for the water spraying system

Display field



Each actuation of the function key [F2] switches between:

- Operating hours
- Asphalt temperature in °C (*optional equipment*)
- Asphalt temperature in °F (*optional equipment*)

Fig. 48

5.1 General

If you are not yet acquainted with the controls and indicating elements on this machine you should thoroughly read chapter "Indicators and control elements" before starting work.

All indicators and control elements are described in detail in this chapter.

5.2 Checks prior to start up

Before the everyday use or before a longer working period the following tests and inspections must be performed.



WARNING!

Please observe strictly the safety regulations in the corresponding section of this instruction manual!

Park the machine on ground as level as possible.

Check:

Hydraulic oil tank and lines for leaks

Fuel tank and fuel lines for leaks

Cooling system for contamination, damage and leaks

Screw connections

Engine and exhaust system for leaks

Belt drive for damage

Function of steering

Function of brake

Function of emergency stop

Function of backup alarm system

Function of seat contact switch

Machine for cleanliness and for damage

Presence of the appropriate operating and maintenance instructions

Proper maintenance of the machine

Air pressure in rubber tyres (only ACM/ SCC-machines)

i *For a description of the following tasks refer to the chapter "maintenance every 10 operating hours".*

Engine oil level, top up if necessary

Fuel level, top up if necessary

Hydraulic oil level, top up if necessary

Hydraulic oil filter element, change if necessary

Coolant level, top up if necessary

Water level, top up if necessary

Emulsion level, top up if necessary (only ACM-/SCC-machines)

5.3 Electronic immobilizer

i *Optional equipment*

Before starting the engine the anti-theft protection* must be disarmed by entering a code.

i *With the electronic immobilizer armed, the light emitting diode (a) flashes slowly.*




Fig. 49

Slowly enter the six-digit user code.

⇒ When entering the code, the light emitting diode (6) lights up with every digit.

Press the diamond button.

⇒ The electronic immobilizer is now disarmed and the engine can be started within the next 15 minutes.

5.4 Adjusting the driver's seat



WARNING!

Danger of accident!

Do not adjust the driver's seat while driving.

Make sure that all settings are securely locked.




Fig. 50

Use lever (a) ➞ Fig. 50 to adjust to the weight of the operator.



In its adjustment lever (a) is locked in upwards direction. This lock can be released by pressing the lever completely down against the stop. Then adjust to the weight of the operator by sliding the lever down.

Pull up lever (b) and adjust the seat in longitudinal direction by sliding it forward or back.

Pull up lever (c) and adjust the backrest.

Make sure that all settings are securely locked.

5.5 Starting the engine



WARNING!

Danger of accident! Danger of injury!

Wear your personal noise protection means (ear defenders) before starting operation.

Start and operate the machine only from the driver's seat.

Prerequisites:

- Main battery switch switched on (*optional equipment*)
- Travel lever in parking brake position
- Unlock the emergency stop switch



When closing the dashboard cover the Emergency Stop switch will lock automatically and must be unlocked before starting again.

Fasten your seat belt.

Set the throttle lever to position "MIN".




Fig. 51

Operation – Starting the engine




Fig. 52



Fig. 53




Fig. 54

Turn the ignition key to position "I".

⇒ All control and warning lamps in the instrument cluster light up a moment.

With cold ambient temperatures hold the ignition key up to 10 seconds in position "II".

⇒ The preheating control lamp lights up.

i *The starter switch is designed with a re-start lock. The ignition key must first be turned back to position "0" before a new starting attempt can be made.*



NOTICE!

Components may get damaged!

- Run the starting process for maximum 20 seconds without interruption and pause for a minute between starting attempts.
- If the engine has not started after two attempts, determine the cause.

Turn the ignition key through position "II" to position "III".

⇒ The starter cranks the engine.



NOTICE!

Run the engine warm for a short while before starting work. Do not rev up a cold engine to high idle speed/full load speed.

5.6 Driving the machine



WARNING!

Life hazard! Danger of accident!

Wet and loose soils considerably reduce the ground adhesion of the machine on inclinations and slopes.

Soil conditions and weather influences impair the climbing ability of the machine.

Do not drive up and down inclinations which exceed the maximum gradability of the machine (see chapter "technical data").

Driving across slopes should therefore be strictly avoided, because of the high risk of tipping over and the related risk of severe or even fatal accidents.

You should therefore always drive straight up or down a slope.

For rollers with a drum width of 1 m (3.3 ft) or less there is a considerable risk of tipping over near edges (e.g. curbstones, embankments, trenches, potholes) when driving over these edges.

Do not drive without wearing your seat belt.

Always give way to loaded transport vehicles!

Before starting to drive make sure that the drive range is absolutely safe.

» Continued on the next page

Drive and operate the machine only from the driver's seat.

Do not drive the machine with the hydraulic breaker connected.^{Optional equipment}

Do not switch on the rotary switch for hydraulic breaker¹ while driving. The machine would be abruptly braked without braking delay.




Fig. 55

Turn the rotary switch for hydraulic breaker anti-clockwise to position "0".




Fig. 56

Set the throttle lever to position "Max I" or "MAX II".



NOTICE!

During operation the throttle lever always remains engaged in full load position "MAX I" or "MAX II". Control the travel speed with the travel lever.

Operation – Driving the machine




Fig. 57

! NOTICE!

Do not operate jerkily!

Disengage the travel lever out of braking position and move it slowly to the desired travel direction.

Position "I"	Forward/reverse travel up to approx. 5 km/h (3.1 mph)
Position "II"	Forward/reverse travel up to approx. 10 km/h (6.2 mph)

Important notes on travel operation

! NOTICE!

- When changing the travel direction hold the travel lever for a moment in "0"-position, until the machine has stopped, before actuating to the new travel direction.

Do not operate jerkily! Control the travel speed with the travel lever.

When driving up and down inclinations move the travel lever slowly back towards neutral to brake the machine.

5.6.1 Seat contact switch



Fig. 58

If the operator leaves his seat while travelling, the driver's seat warning lamp will light up. The warning buzzer sounds and the engine is shut down after two seconds and the parking brake is applied.

If the seat is occupied again within 2 seconds both the warning lamp and the warning buzzer will go out.

If the travel lever is moved out of parking brake position while the engine is stopped and the seat is not occupied, the engine will be shut down immediately.

If the engine stops, occupy the driver's seat and restart the engine ↗ *Chapter 5.5 „Starting the engine“ on page 95.*

5.7 Stopping the machine, operating the parking brake




Fig. 59

Shift the travel lever slowly back to neutral position and lock it in parking brake position.




Fig. 60

⇒ The machine is automatically braked by the hydrostatic drive and the parking brake is applied after approx. 2 seconds. The parking brake warning lamp lights up.

5.8 Shutting down the engine




Fig. 61




Fig. 62




Fig. 63




Fig. 64

Shift the travel lever slowly back to neutral position and lock it in parking brake position.

⇒ The machine is automatically braked by the hydrostatic drive and the parking brake is applied after approx. 2 seconds. The parking brake warning lamp lights up.

Set the throttle lever to position "MIN" (idle speed).



NOTICE!

Danger of engine damage!

- Do not shut down the engine all of a sudden from full load speed, but let it idle for about two minutes.

Turn the ignition key to position "0" and pull it out.

Operation – Shutting down the engine



WARNING!

Danger of accident!

Secure the machine against unauthorized use, pull the ignition key out.

Mark machines, which could be in the way, with a clearly visible sign.

5.9 Switching the vibration on/off

5.9.1 Preliminary remarks and safety notes



NOTICE!

Possible damage to neighbouring buildings!

- When compacting with vibration you must always check the effect of the vibration on nearby buildings and underground supply lines (gas, water, sewage, electric power).
- If necessary stop compacting with vibration.



NOTICE!

Components may get damaged!

- Do not activate the vibration on hard (frozen, concrete) ground.

Vibration at standstill causes transverse marks

- Switch the vibration on only after shifting the travel lever to the desired travel direction.
- Switch the vibration off before stopping the machine.

In automatic operation, vibration is automatically activated when a certain low travel speed is reached. The vibration is automatically switched off when falling below this certain slow travel speed.

This avoids the formation of transverse marks caused by vibration with the machine at standstill.

5.9.2 Vibration in manual mode

i *The rotary switch for drum pre-selection is not installed in ACM/SCC-machines.*

Use the rotary switch for drum pre-selection to pre-select the desired drum(s).

i *Drum pre-selection is only activated, if the vibration has been switched off beforehand.*




Fig. 65




Fig. 66

Turn the rotary switch for vibration pre-selection to position "left".




Fig. 67

Set the throttle lever to position "Max I" or "MAX II".




Fig. 68

a Push button vibration



NOTICE!

Vibration at standstill causes transverse marks!

- Do not switch on vibration with the machine at standstill.

Shift the travel lever slowly to the desired travel direction.

Press the vibration push button on the travel lever.

⇒ Vibration is switched on.

Press the vibration push button ↗ Fig. 68 again or turn the rotary switch for vibration pre-selection ↗ Fig. 69 to position "0".




Fig. 69

5.9.3 Vibration in automatic mode



The rotary switch for drum pre-selection is not installed in ACM/SCC-machines.

Use the rotary switch for drum pre-selection to pre-select the desired drum(s).



Drum pre-selection is only activated, if the vibration has been switched off beforehand.




Fig. 70

Operation – Switching the vibration on/off




Fig. 71

Turn the rotary switch for vibration pre-selection to position "Right".




Fig. 72

Shift the travel lever slowly to the desired travel direction.

⇒ The vibration comes on at a low travel speed.




Fig. 73

To switch off vibration return the travel lever ↗ Fig. 72 towards "0" or switch the rotary switch for vibration pre-selection ↗ Fig. 73 to position "0".

5.10 Operating the Economizer

The Economizer continuously informs the driver about the compaction status and enables the detection and selected re-compaction of weak spots.




Fig. 74

The acceleration transducer on the front drum ↗ Fig. 74 measures the reaction of the road subbase or the different asphalt layers on the vibrating drum.




Fig. 75

The increasing number of yellow LEDs (1) - (10) ↗ Fig. 75 lighting up indicates the increase in compaction.

If the number of yellow LEDs does not increase any further, no further compaction can be achieved with this machine.

The red LED (a) flashes when the system is unable to determine an assessable measuring value (e.g. jump operation of the drum caused by a hard subbase, acceleration sensor not connected or cable breakage).

In order to achieve the desired soil stiffness or asphalt density, one must always perform a suitable reference measurement before compaction is started.

This is necessary to find out how many LEDs in the Economizer display correspond with the required soil stiffness value or asphalt density on the soil being compacted.

i *Tandem rollers of the same type show identical measuring values when used on the same soil.*

The measuring values achieved with different tandem rollers with Economizer from BOMAG can be made comparable by calibration to a reference value.

i *The Economizer is maintenance free.*

Starting the measuring system

The measuring system is automatically started when switching on the machine.

The system first performs an LED-test. The LEDs light up one after the other, starting with LED (1) → Fig. 76. Once all LEDs are on, the display goes out again in single steps.




Fig. 76




Fig. 77

After switching on the vibration the red LED (a) → Fig. 77 flashes for approx. 1 - 2 seconds, until the vibration motor has reached its nominal frequency. Then the red LED goes out.

The system is now in measuring mode.

i *If the red LED still flashes or lights up, see chapter "Notes on operation".*

Notes on operation

Display	Explanation:
The maximum display value will not be reached, even after many passes.	Due to different soil stiffness values or asphalt densities the maximum value will not be reached in each case.
The display varies during a pass by one LED up/down:	Due to minor fluctuations in the material composition and the filling height of the road subbase or the asphalt paving thickness, the value may fluctuate. The average of the display reading during the last pass is decisive.
The red LED is flashing	The system is unable to determine an assessable measuring value (e.g. jump operation of the drum caused by a hard subbase, acceleration sensor not connected or cable breakage). The last valid measuring value will be displayed, until a new measuring value has been determined.
The red LED lights up.	The system is unable to read a calibration value when starting. Since this value is required for calculation the measuring values, measuring operation is blocked. Restart the measuring system. Turn the ignition key back to position "0" and then again to position "I". If the warning lamp still light, please contact our customer service.

Operation – Operating the Economizer

Display	Explanation:
The displayed measuring values are not plausible.	The acceleration sensor is not fastened correctly.
	Shut down the engine and check the fastening screws for the acceleration transducer. Both screws must be tight.
	Weak spots in the road subbase are also measured when paving asphalt. In unfavourable cases an excessively varying material composition or moisture can influence the measuring results. On considerably dry or excessively moist material lower measuring values will be displayed.

5.11 Switching the pressure sprinkling system on and off




Fig. 78

Switch the interval switch for pressure sprinkling ➞ Fig. 78 to the desired flow interval.

Position "0"	Sprinkling off
Position "1" to "4"	various sprinkling intervals
Position "5"	Permanent sprinkling




Fig. 79

To switch on the sprinkling system pull the travel lever ➞ Fig. 79 out of braking position.



With the travel lever in neutral position and interval switch in position "5" (permanent sprinkling) the sprinkling system is already active.

With interval sprinkling the machine needs to drive forward or backward.

With the travel lever in neutral position sprinkling will continue for another 15 seconds.

To switch off the pressure sprinkling system switch the interval switch for pressure sprinkling ➞ Fig. 78 to position "0".

Operation – Switching the pressure sprinkling system on and off




Fig. 80

i When sprinkling the edge cutting unit the lever of the shut-off valve
↪ Fig. 80 must be positioned in flow direction. *Optional equipment*

Test position




Fig. 81

Check on the water level indicator
↪ Fig. 81 whether the water tank is sufficiently filled.



NOTICE!

In test position the water pump will be running.

Do not remain too long in test position, because the water pump may get damaged when the water tank is empty or the batty will be discharged.




Fig. 82

To test the pressure sprinkling system shut down the engine and set the ignition key
↪ Fig. 82 to position "I".

Operation – Switching the pressure sprinkling system on and off




Fig. 83

Set the interval switch for pressure sprinkling → Fig. 83 to position "5" (permanent sprinkling).

The pressure sprinkler system is switched on.

Check water output and spray pattern on all nozzles.

i *In positions "1" to "4" the corresponding interval is activated once. Then the pump is switched off.*

5.12 Switching emulsion sprinkling on/off

i Only on ACM/SCC-machines.




Fig. 84

Actuate the foot switch.

⇒ Emulsion sprinkling switched on.

Release the foot switch.

⇒ Emulsion sprinkling switched off.

5.13 Setting the crabwalk



WARNING!

Danger of accident! Life hazard!

Lifting tackle must only be attached to loads by expert personnel (qualified person).

Always use shackles on the lifting points to lift the machine.

Check all lifting points and fastening elements for damage before lifting the machine. Do not use damaged or in any other way impaired lifting points.

Lift the machine only with suitable lifting gear. Use only safe lifting gear of sufficient load bearing capacity. Minimum lifting capacity of lifting gear: see operating weight in chapter "Technical Data".

Do not lift or lower the machine jerkily.

The tension must always be effective in vertical direction.

The machine must not swing about when being lifted.

Do not step or stand under suspended loads.

Operation – Setting the crabwalk




Fig. 85

Lift up the machine by the central lifting device ↗ Fig. 85 so that it is just above the ground.




Fig. 86

Disengage the articulation lock ↗ Fig. 86.

Slightly loosen the screws (1).

Displace the front frame.

Lower the machine to the ground.

Tighten the screws, tightening torque.
300 Nm (221 ft.lbs).

5.14 What to do in events of emergency

Actuating the emergency stop switch



WARNING!

Danger of accident!

In events of emergency and in case of danger actuate the emergency stop switch immediately.

Start travel operation of the machine only after the danger that caused the actuation of the emergency stop switch has been eliminated.



NOTICE!

Do not use as service brake. The deceleration is extremely high. In case of frequent use the wear on the multi-discs brakes will be very high.



Fig. 87

Press the button of the emergency stop switch ↘ Fig. 87 completely down, it automatically locks in fully pressed position.



Shuts the engine down and closes the brake.

Turn the button clockwise to unlock the emergency stop switch.

Start the engine again, see chapter "Starting the engine".

Disconnecting the battery



WARNING!

In order to be able to disconnect the battery quickly in case of danger (e.g. cable fire or electrical malfunction) the minus terminal has been designed as a quick release pole clamp.




Fig. 88

Fold up the covering flap in the foot well
↪ Fig. 88.




Fig. 89

Pull up the cap from the minus pole
↪ Fig. 89. The pole clamp on the minus pole thereby becomes loose.

Disconnect the pole clamp from the minus pole of the battery and lay it to the side.

5.15 Mounting the edge cutter tool

i *The edge cutter is an option.*

Shut down the engine, pull off the ignition key

Loosen the star handle screw ↗ Fig. 90 on the front drum.




Fig. 90

Attach the cutting or compacting tool and fasten it with the star handle screw ↗ Fig. 91.




Fig. 91

5.16 Lifting / lowering the edge cutter

i *The edge cutter is an option.*



WARNING!

Danger of squashing!

When lowering the edge cutter there is a danger of body parts being crushed or cut off.

Make absolutely sure that there are no persons in the danger zone.




Fig. 92

Press button (c)  Fig. 92 on the travel lever right to lift the edge cutter.

Press button (d) on the travel lever right to lower the edge cutter.

5.17 Connecting/disconnecting the hydraulic breakerOptional equipment ment



WARNING!

Danger of accident!

Do not drive the machine with the hydraulic breaker connected.



NOTICE!

Once the rotors switch for the hydraulic breaker has been switched to the right, the hydraulic breaker is active. The parking brake is applied at the same time. The machine is no longer able to drive. Always keep the travel lever in parking brake position.

Connecting the hydraulic breaker




Fig. 93

Stop the machine. Shift the travel lever
↩ Fig. 93 slowly back to neutral position
and lock it in parking brake position.




Fig. 94

Before connecting hydraulic lines to the couplings make sure that the rotary switch for the hydraulic breaker ↷ Fig. 94 is in position "0".



NOTICE!

Contaminants or dirt must not enter into the hydraulic circuit.




Fig. 95

Clean the hydraulic couplings ↷ Fig. 95. Connect the hydraulic breaker to the couplings.




Fig. 96

Turn the rotary switch for hydraulic breaker ↷ Fig. 96 clockwise.




Fig. 97

Set the throttle lever to position "MAX II".

The hydraulic breaker can now be used.

Connecting the hydraulic breaker




Fig. 98

Set the throttle lever to position "MIN".




Fig. 99

Turn the rotary switch for hydraulic breaker
↶ Fig. 99 anti-clockwise to position "0".

Disconnect the hydraulic breaker from the couplings .

5.18 Towing

5.18.1 Towing AD/ADM/SC-machines



WARNING!

Danger of accident!

Apply appropriate measures (e.g. with metal wheel chocks, to be provided by the operating company) to secure the machine against rolling away before releasing the parking brake.

Use a towing vehicle with sufficient traction and braking power for the unbraked towed load.

Use a tow bar (to be provided by the operating company).

The machine cannot be steered.



NOTICE!

Tow the machine only after having released the parking brake.

Max. towing speed 1 km/h (0.6 mph), max. towing distance 500 m (0.3 mi).




Fig. 100

Mount the towbar to the front or rear towing eye (1).

Release the brake.

i *Release the brakes in both drums.*

Remove two plugs.




Fig. 101




Fig. 102

Press both screws in against the springs.

Tighten both screws alternately and in steps with 35 Nm (25.8 ft.lbf) until they bottom.

Screw both plugs back in, tightening torque: 50 Nm (37 ft.lbf).

After towing



WARNING!

Danger of accident!

Apply appropriate measures to secure the machine against rolling away (e.g. with metal wheel chocks, to be provided by the operating company) before disconnecting the tow bar.

The machine must only be started without the mechanical brake releasing device being activated.

After towing close the brakes on both drums again.




Fig. 103

Remove two plugs.




Fig. 104

Completely release both screws to close the brake.




Fig. 105

Screw both plugs back in, tightening torque: 50 Nm (37 ft·lbf).

Close also the brake on the second drum.

5.18.2 Towing ACM/SCC-machines



WARNING!

Danger of accident!

Apply appropriate measures (e.g. with metal wheel chocks, to be provided by the operating company) to secure the machine against rolling away before releasing the parking brake.

Use a towing vehicle with sufficient traction and braking power for the unbraked towed load.

Use a tow bar (to be provided by the operating company).

The machine cannot be steered.




NOTICE!

Tow the machine only after having released the parking brake.

Max. towing speed 1 km/h (0.6 mph), max. towing distance 500 m (0.3 mi).


Operation – Towing



Mount the towbar to the front or rear towing eye (1).

Fig. 106

Releasing the brake



Unscrew the locking screw (1) and switch the ball valve (*optional equipment*) to position "I".

Turn the steering wheel slowly approx. two turns in clockwise direction.

Fig. 107

After towing



WARNING!

Danger of accident!

Apply appropriate measures to secure the machine against rolling away (e.g. with metal wheel chocks, to be provided by the operating company) before disconnecting the tow bar.

The machine must only be started without the mechanical brake releasing device being activated.

Always secure the ball valve of the brake releasing feature with the locking screw.




Fig. 108

Switch the ball valve back to position "0", turn the locking screw (1) back in and counter it with the hexagon nut.

5.19 Loading/transport

Loading with loading ramp



WARNING!

Danger of accident! Life hazard!

Use only stable loading ramps of sufficient load bearing capacity. The ramp inclination must be less than the gradability of the machine.

Loading ramps must be free of grease, oil, snow and ice.

Make sure that persons are not endangered by the machine tipping or sliding off.

During demonstration and when loading the machine do not remain in the danger zone of the machine.

Secure the machine with the articulation lock after driving it on the transport vehicle.

Drive the machine carefully on the transport vehicle.




Fig. 109

After driving the machine onto the transport vehicle attach and secure the articulation lock → Fig. 109.




Fig. 110

Fold down the foldable ROPS for transport. Loosen the eye bolts  Fig. 110 and adjust the clamping plates vertically. ^{Optional equipment}

Fold the foldable ROPS back.

Loading by crane



WARNING!

Danger of accident! Life hazard!

Lifting tackle must only be attached to loads by expert personnel (qualified person).

Engage the articulation lock.

Always use suitable lifting tackle on the lifting points to lift the machine.

Check all lifting points and fastening elements for damage before lifting the machine. Do not use damaged or in any other way impaired lifting points.

Lift the machine only with suitable lifting gear. Use only safe lifting gear of sufficient load bearing capacity. Minimum lifting capacity of lifting gear: see operating weight in chapter "Technical Data".

Do not lift or lower the machine jerkily.

The tension must always be effective in vertical direction.

The machine must not swing about when being lifted.

Do not step or stand under suspended loads.

Fold down the foldable ROPS^{Optional equipment}

Engage the articulation lock.




Fig. 111

Lashing



WARNING!

Danger of accident! Life hazard!

Always use suitable lashing gear on the lifting points to lash down the machine.

Check all lashing points for damage before lashing down the machine. Do not use a damaged or in any other way impaired lashing points.

Lash the machine down, so that it is secured against rolling, sliding and turning over.

Always apply the articulation lock for transportation.




Fig. 112

Lash the machine to the transport vehicle, use the lashing eyes ↗ Fig. 112 on front and rear frame for this purpose.

After transport



WARNING!

Life hazard!

Operate the machine only with the foldable ROPS properly fastened and the fastening screws tightened with the correct tightening torque. ^{Optional equipment}

After transport release the articulation lock again and store it in the receptacle.




Fig. 113

After transportation loosen the articulation lock ➞ Fig. 113.




Fig. 114

To fold up the foldable ROPS align the clamping plates on both sides vertically ➞ Fig. 114.




Fig. 115

Fold up the foldable ROPS ↘ Fig. 115.

Turn the clamping plates to horizontal position and tighten the eye bolts with a tightening torque of 50 – 80 Nm (37 – 60 ft.lbf).

6.1 General notes on maintenance

Always comply with the appropriate safety regulations when performing maintenance work.

Thorough maintenance of the machine guarantees far longer safe functioning of the machine and prolongs the lifetime of important components. The effort needed for this work is only little compared with the problems that may arise when not observing this rule.

The terms right/left correspond with travel direction forward.

Always clean machine and engine thoroughly before starting maintenance work.

Do not touch hot engine parts.

For maintenance work stand the machine on level ground.

Always remove the main battery switch for all maintenance work.

Perform maintenance work only with the engine shut down.

Relieve hydraulic pressures before working on hydraulic lines.

Before working on electric parts of the machine disconnect the battery and cover it with insulation material.

When working in the area of the articulated joint attach the articulation lock (transport lock).



ENVIRONMENT!

During maintenance work catch all oils and fuels and do not let them seep into the ground or into the sewage system. Dispose of oils and fuels environmentally.

Keep used filters in a separate waste container and dispose of environmentally.

Catch biodegradable oils separately.

Notes on the fuel system

The lifetime of the diesel engine depends to a great extent on the cleanliness of the fuel.

Keep fuel free of contaminants and water, since this will damage the injection elements of the engine.

Drums with inside zinc lining are not suitable to store fuel.

When choosing the storage place for fuel make sure that spilled fuel will not harm the environment.

Do not let the hose stir up the slurry at the bottom of the drum.

The fuel drum must rest for a longer period of time before drawing off fuel.

Fuel residues in the drum are not suitable for the engine.

Notes on the performance of the engine

On diesel engines both combustion air and fuel injection quantities are thoroughly adapted to each other and determine power, temperature level and exhaust gas quality of the engine.

Maintenance – General notes on maintenance

If your engine has to work permanently in "thin air" (at higher altitudes) and under full load, you should consult our customer service or the customer service of the engine manufacturer.

Notes on the cooling system

Prepare and check coolant with highest care, since otherwise the engine may be damaged by corrosion, cavitation and freezing.

The coolant is prepared by mixing a cooling system protection agent (ethylene glycol) into the coolant.

Mixing with cooling system protection agent is necessary in all climatic zones. It prevents corrosion, lowers the freezing point and raises the boiling point of the coolant.

Notes on the hydraulic system

During maintenance work on the hydraulic system cleanliness is of major importance. Make sure that no dirt or other contaminating substances can enter into the system. Small particles can produce flutes in valves, cause pumps to seize, clog nozzles and pilot bores, thereby making expensive repairs inevitable.

If, during the daily inspection of the oil level the hydraulic oil level is found to have dropped, check all lines, hoses and components for leaks.

Seal external leaks immediately. If necessary inform the responsible customer service.

Do not store drums with hydraulic oil outdoors, or at least under a cover. Water can be drawn in through the bung hole when the weather changes.

Maintenance – General notes on maintenance

We recommend to use our filling and filtering unit with fine filter to fill the system. This ensures finest filtration of the hydraulic oil, prolongs the lifetime of the hydraulic oil filter and protects the hydraulic system.

Clean fittings, filler covers and the area around such parts before disassembly to avoid entering of dirt.

Do not leave the tank opening unnecessarily open, but cover it so that nothing can fall in.

6.2 Fuels and lubricants

6.2.1 Engine oil

6.2.1.1 Oil quality

The following engine oil specifications are permitted:

- Engine oils as per API-classification CF, CF-4, CG-4, CH-4 and CI-4

For operation of an engine with high sulphur fuels we recommended to use an engine oil of API-classification CF or higher with a total base number of at least 10.

Avoid mixing engine oils.

6.2.1.2 Oil viscosity

Since engine oil changes its viscosity with the temperature, the ambient temperature at the operating location of the engine is of utmost importance when choosing the viscosity class (SAE-class).

The temperature data of the SAE-class always refer to fresh oils. In travel operation engine oil ages because of soot and fuel residues. This adversely affects the properties of the engine oil, especially under low ambient temperatures.

Optimal operating conditions can be achieved by using the following oil viscosity chart as a reference:

Ambient temperature	Oil viscosity
higher than 25 °C (77 °F)	SAE 30
	SAE 10W-30
	SAE 15W-40
-10 °C to 25 °C (14 °F to 77 °F)	SAE 10W-30
	SAE 15W-40
below - 10 °C (14 °F)	SAE 10W-30

6.2.1.3 Oil change intervals

If the oil change intervals are not reached over a period of one year, the oil change should be performed at least 1 x per year, irrespective of the operating hours reached.

If the sulphur content in the fuel is higher than 0.5 %, the oil change intervals must be halved.

6.2.2 Fuel

6.2.2.1 Fuel quality

We recommend using a diesel fuel with a sulphur content of less than 0.1 %.

When using a diesel fuel with a high sulphur content of 0.5 % to 1.0 % the oil change intervals must be halved.

Fuels with a sulphur content of more than 1.0 % are not permitted.

In order to fulfil national emission regulations one must strictly use the legally required fuels (e.g. sulphur content).

For engines used in EPA areas, the use of diesel fuels with ultra-low sulphur content is mandatory (ASTM D975 Grade-No. 1-D S15 and 2-D S15).

(EPA: United States Environmental Protection Agency)

The recommended Cetan index number is 45. A Cetan index number higher than 50 should preferably be used, especially at ambient temperatures below -20 °C (-4 °F) and when working at altitudes of more than 1500 m (4921 ft).

The following fuel specifications are recommended:

- EN 590
- ASTM D975 Grade-No. 1-D and 2-D

6.2.2.2 Winter fuel

For winter operation use only winter diesel fuel, to avoid clogging because of paraffin separation.

At very low temperatures disturbing paraffin separation can also be expected when using winter diesel fuel.

Diesel fuels suitable for temperatures down to -44 °C (-47 °F) are available for Arctic climates.



NOTICE!

Danger of engine damage!

- The admixture of petroleum and the addition of “flow enhancing additives” (fuel additives) is not permitted.

6.2.2.3 Storage

Even traces of zinc, lead and copper can cause deposits in the injection nozzles, especially in modern Common-Rail injection systems.

Zinc and lead coatings in refuelling systems and fuel lines are not permitted.

Copper containing materials (copper lines, brass items) should be avoided, because they can cause catalytic reactions in the fuel with subsequent depositing in the injection system.

6.2.3 Coolant

Always use a mixture of anti-freeze agent and clean, dehardened water with a mixing ratio of 1:1.

Under particularly extreme temperature conditions you should consult our customer service concerning the anti-freeze agent to be used.

There are various types of anti-freeze agents available. For this engine you should use ethylene glycol.

Before filling in the coolant mixed with anti-freeze agent the radiator must be flushed with clean water. This procedure should be repeated two to three times to clean the inside of radiator and engine block.



NOTICE!

Danger of engine damage!

- Do not mix different coolants and additives of any other kind.

Mixing the coolant:

- Prepare a mixture of 50% anti-freeze agent and 50% low mineral, clean water.
- Stir well before filling it into the radiator.
- The method of mixing water and anti-freeze depends on the brand of the anti-freeze agent (see standard SAE J1034 and also standard SAE J814c).

Add anti-freeze agent:

- If the coolant level drops because of evaporation, only clean water is to be used for topping up.
- In case of leakages you must always fill in anti-freeze agents of the same brand and the same mixing ratio.

Do not use any radiator cleaning agent after the anti-freeze agent has been mixed in. The anti-freeze agent also contains a corrosion protection agent. If this mixes with cleaning agent it may cause the development of sludge, which could damage the cooling system.

Anti-freeze concentration	Freezing point
50 %	-37 °C (-35 °F)

6.2.4 Hydraulic oil

6.2.4.1 Mineral oil based hydraulic oil

The hydraulic system is operated with hydraulic oil HV 46 (ISO) with a kinematic viscosity of 46 mm²/s at 40 °C (104 °F) and 8 mm²/s at 100 °C (212 °F).

For topping up or for oil changes use only hydraulic oil, type HVLP according to DIN 51524, part 3, or hydraulic oils type HV according to ISO 6743/3.

The viscosity index (VI) should be at least 150 (observe information of manufacturer).

6.2.4.2 Bio-degradable hydraulic oil

The hydraulic system can also be operated with a synthetic ester based biodegradable hydraulic oil.

The biologically quickly degradable hydraulic oil Panolin HLP Synth.46 meets all demands of a mineral oil based hydraulic oil according to DIN 51524.

In hydraulic systems filled with Panolin HLP Synth.46 always use the same oil to top up.

When changing from mineral oil based hydraulic oil to an ester based biologically degradable hydraulic oil, you should consult the lubrication oil service of the oil manufacturer, or our customer service for details.



NOTICE!

Danger of damage to the hydraulic system!

- After the changeover check the hydraulic oil filters increasingly for contamination.
- Have regular oil analyses performed regarding the water content and mineral oil.
- Replace the hydraulic oil filter at the latest after 500 operating hours.

6.3 List of fuels and lubricants

Assembly group	Fuel or lubricant		Spare parts number	Filling quantity
	Summer	Winter		Observe the level mark!
Engine oil	SAE 10W-40		009 920 06	3.9 l
	Specification: ↗ Chapter 6.2.1 „Engine oil“ on page 144		20 l	(1.0 gal us)
	SAE 10W-30			
	SAE 15W-40			
	SAE 30			
Fuel	Diesel	Winter diesel fuel		30 l
	Specification: ↗ Chapter 6.2.2 „Fuel“ on page 145			(7.9 gal us)
Coolant	Mixture of water and anti-freeze agent		009 940 03	9 l
	Specification: ↗ Chapter 6.2.3 „Coolant“ on page 147		20 l	(2.4 gal us)
Hydraulic system	Hydraulic oil (ISO), HVLP 46		009 930 09	14 l
	Specification: ↗ Chapter 6.2.4.1 „Mineral oil based hydraulic oil“ on page 148		20 l	(3.7 gal us)
	or ester based biodegradable hydraulic oil			
	Specification: ↗ Chapter 6.2.4.2 „Bio-degradable hydraulic oil“ on page 149			

Maintenance – List of fuels and lubricants

Assembly group	Fuel or lubricant		Spare parts number	Filling quantity
	Summer	Winter		Observe the level mark!
Spraying system	Water	Anti-freeze mixture		100 l (26.4 gal us)
Emulsion spraying system	Emulsion			11 l (2.9 gal us)

6.4 Running-in instructions

The following maintenance work must be performed when running in new machines or overhauled engines:



NOTICE!

Up to approx. 250 operating hours check the engine oil level twice every day.

Depending on the load the engine is subjected to, the oil consumption will drop to the normal level after approx. 100 to 250 operating hours.

Maintenance after 50 operating hours

Check the engine for leaks

Retighten the fastening screws on air filter, exhaust and other attachments.

Check screw connections on the machine, retighten as necessary.

6.5 Maintenance Table

No.	Maintenance works	Page
Every 10 operating hours		
6.6.1	<i>Check the engine oil level</i>	155
6.6.2	<i>Check the fuel level</i>	156
6.6.3	<i>Checking the hydraulic oil level</i>	157
6.6.4	<i>Checking the hydraulic oil filter element</i>	158
6.6.5	<i>Checking the coolant level</i>	159
6.6.6	<i>Checking the water level</i>	160
6.6.7	<i>Check the emulsion level</i>	160
Every 50 operating hours		
6.7.1	<i>Checking, cleaning the air filter, replacing if necessary</i>	162
6.7.2	<i>Check fuel lines and clamps</i>	165
6.7.3	<i>Checking, cleaning the water separator</i>	166
Every 250 operating hours		
6.8.1	<i>Changing engine oil and oil filter cartridge</i>	167
6.8.2	<i>Checking, tensioning, replacing the V-belt</i>	169
6.8.3	<i>Checking the air intake lines</i>	170
6.8.4	<i>Cleaning radiator and hydraulic oil cooler</i>	171
6.8.5	<i>Battery service</i>	173
6.8.6	<i>Checking radiator hoses and hose clamps</i>	175
6.8.7	<i>Check scrapers, adjust if necessary</i>	176
Every 500 operating hours		
6.9.1	<i>Drain the fuel tank sludge</i>	178
6.9.2	<i>Change the fuel filter</i>	179
6.9.3	<i>Check the anti-freeze concentration and the condition of the coolant</i>	180
Every 1000 operating hours		
6.10.1	<i>Checking, adjusting the valve clearance</i>	182

Maintenance – Maintenance Table

No.	Maintenance works	Page
6.10.2	<i>Check the engine mounts</i>	184
6.10.3	<i>Check the travel control</i>	184
<i>Every 2000 operating hours</i>		
6.11.1	<i>Changing hydraulic oil and breather filter</i>	185
6.11.2	<i>Replacing the hydraulic oil filter</i>	189
6.11.3	<i>Changing the coolant</i>	190
6.11.4	<i>Replacing the fuel lines</i>	193
6.11.5	<i>Check the injection nozzles</i>	194
<i>Every 3000 operating hours</i>		
6.12.1	<i>Check the fuel injection pump</i>	195
<i>As required</i>		
6.13.1	<i>Checking the air pressure in the rubber tires</i>	196
6.13.2	<i>Water sprinkler system, maintenance in case of frost</i>	196
6.13.3	<i>Tightening torques for screws with metric unified thread</i>	198
6.13.4	<i>Measures to be applied for longer periods of rest</i>	198

6.6 Every 10 operating hours

6.6.1 Check the engine oil level



NOTICE!

The machine must be in horizontal position. When the engine is warm, shut it down and check the oil level after five minutes. With a cold engine the oil level can be checked immediately.

For quality of oil refer to the "table of fuels and lubricants".




Fig. 116

Pull the dipstick  Fig. 116 out, wipe it off with a lint-free, clean cloth and reinsert it until it bottoms.


Pull the dipstick back out.

The oil level must always be between the "MIN"- and "MAX"-marks.

If the oil level is too low top up oil immediately.

If the oil level is too high, determine the cause and drain the oil off.

6.6.2 Check the fuel level



Check the fuel level on the fuel gauge
→ Fig. 117.

Fig. 117

Refuelling



WARNING! **Fire hazard!**

When working on the fuel system
do not use open fire, do not smoke,
do not spill any fuel.

Do not refuel in closed rooms.

Shut down the engine.



WARNING! **Health hazard!**

Do not inhale any fuel fumes.



NOTICE!

Contaminated fuel can cause malfunction or even damage of the engine. If necessary, fill in fuel through a funnel with screen.

Monitor the entire refuelling process.

For quality and quantity of fuel refer to the "table of fuels and lubricants".



ENVIRONMENT!

Catch running out fuel, do not let it seep into the ground.

Shut down the engine.

Open the engine hood.




Fig. 118

Clean the area around the filler opening.

Open the cover ↗ Fig. 118.

Top up with fuel (diesel or winter diesel).

Screw the cover back on again.

6.6.3 Checking the hydraulic oil level



NOTICE!

If, during the daily inspection of the oil level the hydraulic oil level is found to have dropped, check all lines, hoses and components for leaks.

In hydraulic systems filled with Pan-olin Synth. 46 use only the same oil to top up. With other ester based oils consult the lubrication oil service of the respective oil manufacturer.

For quality of oil refer to the "table of fuels and lubricants".

Maintenance – Every 10 operating hours




Fig. 119

Check the oil level in the oil level inspection glass → Fig. 119.

i *At a room temperature of approx. 20 °C (68 °F) the oil level should reach approx. 2/3 way up the inspection glass.*

If the oil level is too low top up hydraulic oil immediately.

6.6.4 Checking the hydraulic oil filter element



NOTICE!

If the hydraulic oil is very cold the pin may pop up, you should therefore only check the filter and press the pin in at operating temperature.




Fig. 120

Check the contamination indicator → Fig. 120 at operating temperature and with the engine running at maximum speed.

If necessary press the pin in.

Pin remains pressed in	Hydraulic oil filter element o.k.
Pin pops out	Replacing the hydraulic oil filter element

6.6.5 Checking the coolant level



WARNING!

Danger of scalding!

Open the cap on the coolant compensation tank only when the engine is cold.



NOTICE!

If, during the daily inspection the coolant level is found to have dropped, check all lines, hoses and engine for leaks.

For quality of coolant refer to the chapter on "fuels and lubricants".




Fig. 121

Check the coolant level in the compensation tank ↪ Fig. 121.

To top up unscrew the filler cap and fill in coolant up to the MAX-mark.

6.6.6 Checking the water level



NOTICE!

- If there is a risk of frost observe the special service instructions in chapter "water sprinkler system, maintenance in case of frost".

Make sure that the ventilation bore in the filler cap is free.




Fig. 122

Check the water tank filling level on the water level gauge ➞ Fig. 122.




Fig. 123

Open the cover ➞ Fig. 123.

If necessary fill in water through the filler screen and close the cap again.

6.6.7 Check the emulsion level



Only on ACM/SCC-machines.

! NOTICE!

- Different emulsions must not be mixed. If necessary drain off the emulsion beforehand.

For mixing ratio of water and emulsion refer to the specification of the respective manufacturer.

Make sure that the ventilation bore in the filler cap is free.




Fig. 124

Open the lid  Fig. 124 on the tank, fill up with emulsion as necessary and close the lid again.

6.7 Every 50 operating hours

6.7.1 Checking, cleaning the air filter, replacing if necessary



NOTICE!

Perform cleaning, maintenance and repair work only with the engine shut down. Do not start the engine after removing the filter element.

Do not use gasoline or hot fluids to clean the filter element.

After cleaning the filter element must be inspected for damage using a torch.

Air filter cartridge with damaged paper bellows or seal lips must be replaced in any case.

The air filter cartridge must be replaced after 6 times cleaning, but at the latest after one year, irrespective of the operating hours.

Cleaning does not make sense if the main filter cartridge is covered with a sooty deposit. Use a new air filter cartridge.

Incorrectly handled air filter cartridges may become ineffective because of damage (e.g. cracks) and cause damage to the engine.

Open the engine hood.



Under very dusty conditions you may have to check the filter service indicator every day.

Maintenance – Every 50 operating hours




Fig. 125



NOTICE!

After cleaning the air filter press the reset button for the red piston on the filter service indicator.

Under normal conditions open the evacuation valve (2) once per week (or every day under very dusty conditions), in order to remove big dust and dirt particles.

Unclip the clamps on the housing cover (3) and take off the cover .




Fig. 126



NOTICE!

Do not use compressed air to blow out the air filter housing.




Fig. 127



WARNING!

Eye injury!

Wear safety goggles.

Maintenance – Every 50 operating hours

Blow the air filter cartridge ↗ Fig. 127 out with clean and dry compressed air (max. 2 bar (30 psi)) by blowing along the inner creases.



NOTICE!

- Do not hold the compressed air nozzle closer to the filter than 3 cm




Fig. 128

Check the air filter cartridge ↗ Fig. 128 from inside with a torch for holes, cracks, flutes or other damage.

Always replace damaged filter cartridges.




Fig. 129

Before re-installation check the sealing faces on the air filter cartridge ↗ Fig. 129.




Fig. 130

Insert the air filter cartridge, attach the housing cover and fasten with fastening clamps (3) ↗ Fig. 130.



NOTICE!

- If the clamps are not fastened correctly dirt and dust may be drawn in. This can damage the engine.

6.7.2 Check fuel lines and clamps



WARNING!

Danger of burning!

Perform inspection work only after the engine has cooled down and with the engine stopped.



NOTICE!

If fuel lines or hose clamps are found to be damaged, the corresponding parts must be immediately repaired or replaced.

Removed or new fuel lines must be closed with clean cloths on both ends, to make sure that no dirt will enter into the fuel system. Dirt particles can destroy the injection pump.




Fig. 131

Check the condition and tight fit of all fuel lines (1) → Fig. 131 and hose clamps (2).

6.7.3 Checking, cleaning the water separator



WARNING!

Fire hazard! Health hazard!

When working on the fuel system do not use open fire, do not smoke, do not spill any fuel.

Shut down the engine.

Do not inhale any fuel fumes.



The service intervals for the water separator depend on the water content in the fuel and can therefore not be determined precisely. After taking the engine into operation you should therefore check the water separator every day for signs of water.



ENVIRONMENT!

Any fuel must be caught and disposed of in an environmentally friendly manner.




Fig. 132

Slacken the drain plug  Fig. 132 for a few turns and catch running out fuel / water.

Tighten the drain plug again and check for leaks, if necessary replace the seal ring.

6.8 Every 250 operating hours

6.8.1 Changing engine oil and oil filter cartridge



Perform this maintenance work at the latest after one year.



WARNING!

Danger of scalding!

When draining off hot oil.

By hot oil when unscrewing the engine oil filter.



NOTICE!

- The oil change at 250 operating hours refers to the use of fuels with a sulphur content of less than 0.5%. When using fuels with a sulphur content of more than 0.5% the oil change intervals must be halved.

Drain the engine oil only when the engine is warm.

For quality and quantity of oil refer to the "table of fuels and lubricants".



ENVIRONMENT!

Catch running out oil and dispose of environmentally together with the oil filter cartridge.

Maintenance – Every 250 operating hours




Fig. 133

Unscrew the oil filler plug ➤ Fig. 133.




Fig. 134

Unscrew the drain plug ➤ Fig. 134 and catch running out oil.

Turn the oil drain plug back in with a new seal ring.




Fig. 135

Unscrew the filter cartridge ➤ Fig. 135 using an appropriate filter wrench.

Clean the sealing face on the filter carrier from any dirt.




Fig. 136

Slightly oil the rubber seal on the new filter cartridge ➤ Fig. 136.

Turn the new filter cartridge on by hand, until the seal contacts.

Tighten the filter element for another half turn.




Fig. 137

Fill in new engine oil ↗ Fig. 137.
Tighten the oil filler cap properly.




Fig. 138

After a short test run check the oil level once again ↗ Fig. 138, if necessary top up to the top mark (MAX).

6.8.2 Checking, tensioning, replacing the V-belt

Checking the V-belt




Fig. 139

Inspect the entire circumference of the V-belt (1) ↗ Fig. 139 visually for damage and cracks.

Replace a damaged or cracked V-belt immediately.

Check with thumb pressure whether the V-belt can be depressed more than 7 to 9 mm (0.28 – 0.35 inch) between the V-belt pulleys, retighten if necessary.

Tightening the V-belt

Slightly slacken the fastening screws (2) .
Press the generator in direction outward using a lever, until the correct V-belt tension is reached.

Maintenance – Every 250 operating hours

Retighten all fastening screws and check the V-belt tension once again.

Changing the V-belt

Slightly slacken the fastening screws (2) .

Press the generator completely against the engine.

Remove the old V-belt.

Fit the new V-belt to the V-belt pulleys.

Tension the V-belt as previously described.

6.8.3 Checking the air intake lines



WARNING!

Danger of burning!

Perform inspection work only after the engine has cooled down and with the engine stopped.



NOTICE!

Take care that no contaminants enter into the air intake system, since this could damage the engine!

If an air intake hose is damaged, both hose and hose clamp must be replaced immediately.

Check the condition and tight fit of all air intake lines and hose clamps.

6.8.4 Cleaning radiator and hydraulic oil cooler



WARNING!

Danger of injury!

Perform cleaning work only after the engine has cooled down and with the engine stopped.



NOTICE!

Do not damage any cooling fins on the cooler core when cleaning.

Dirt on fan blades and radiator reduce the cooling effect. Dirt deposits in these areas are substantially supported by oil and fuel on these surfaces. For this reason you should always seal any oil or fuel leaks in the vicinity of the cooling fan or the radiator and clean the cooling surfaces after.





Fig. 140

Remove the fan grille ➞ Fig. 140.

Blow the radiator out with compressed air.

Maintenance – Every 250 operating hours



Blow the hydraulic oil cooler ➞ Fig. 141 out with compressed air.

Fig. 141

Cleaning with cold cleansing agent



NOTICE!

- Protect electrical equipment such as generator, regulator and starter against the direct water jet.

Spray engine and cooler with a suitable cleansing agent (e.g. cold cleanser), let it soak in for a while and spray it off with a strong water jet.

Reassemble the fan grille.

Run the engine warm for a while to avoid corrosion.

6.8.5 Battery service



WARNING!

Danger of cauterisation ! Danger of explosion!

When working on the battery do not use open fire, do not smoke!

The battery contains acid. Do not let acid come in contact with skin or clothes!

Wear protective clothing!

Do not lay any tools on the battery!

For recharging remove the plugs from the battery to avoid the accumulation of highly explosive gases.



ENVIRONMENT!

Dispose of the old batteries environmentally.



Maintenance free batteries also need care. Maintenance free only means that the fluid level does not need to be checked. Each battery suffers under self-discharge, which may, if not checked occasionally, even cause damage to the battery as a result of exhaustive discharge.

The following therefore applies for the service life:

Switch off all consumers (e.g. ignition, light, inside light, radio).

Check open-circuit voltage of the battery at regular intervals. At least once per month.

Maintenance – Every 250 operating hours

Reference values: 12.6 V = fully charged; 12.3 V = 50% discharged.

Recharge the battery immediately after an open-circuit voltage of 12.25 V or less is reached. Do not perform quick charging.

The open-circuit voltage of the battery occurs approx. 10 hours after the last charging process or one hour after the last discharge.

After each charging process allow the battery to rest for one hour before taking it into service.

For resting periods of more than one month you should always disconnect the battery. Do not forget to perform regular open-circuit voltage measurements.



NOTICE!

- Exhausted batteries (batteries with formation of sulphate on the plates) are not covered under warranty!



Fig. 142

Fold up the covering hood ➞ Fig. 142.

Maintenance – Every 250 operating hours




Fig. 143

Clean battery ➞ Fig. 143 and battery compartment.

Clean battery poles and pole clamps and grease them with pole grease (Vaseline).

Retighten the pole clamps.

Check the fastening of the battery.

6.8.6 Checking radiator hoses and hose clamps



WARNING!

Danger of burning!

Perform inspection work only after the engine has cooled down and with the engine stopped.



NOTICE!

If a radiator hose is swollen, hardened or cracked, both hose and hose clamp must be replaced immediately.




Fig. 144

Check the condition and tight fit of all radiator hoses and hose clamps ➞ Fig. 144.

6.8.7 Check scrapers, adjust if necessary

Drums



DANGER!

Danger to life caused by machine movements!

- Never step in front of or behind the drums/wheels while the engine is running.




Fig. 145

Check the condition of the scrapers (two each per drum), clean if necessary.

Replace worn scrapers.

Rubber tires



Only on ACM/SCC-machines



DANGER!

Danger to life caused by machine movements!

- Never step in front of or behind the drums/wheels while the engine is running.




Fig. 146

Open the rear door.

Check the condition of the scrapers, clean if necessary.

Replace worn scrapers.

Check the gap between scrapers and rubber tires.

Nominal value:

approx. 2 mm (0.08 in)

If necessary adjust the distance evenly with the screws.

6.9 Every 500 operating hours

6.9.1 Drain the fuel tank sludge



WARNING!

Fire hazard!

When working on the fuel system do not use open fire, do not smoke, do not spill any fuel.



WARNING!

Health hazard!

Do not inhale any fuel fumes.



ENVIRONMENT!

Catch running out fuel, do not let it seep into the ground.



When performing this work the fuel tank shall only hold max. 5 l (1.3 gal us) of fuel, pump off if necessary.




Fig. 147

Place the suitable container under the fuel tank drain plug → Fig. 147.

Unscrew the plug and drain off fuel.

Once all fuel has run out screw the drain plug back in with a new seal ring.

Fill the fuel tank with clean fuel.

6.9.2 Change the fuel filter



WARNING!

Fire hazard!

When working on the fuel system do not use open fire, do not smoke, do not spill any fuel.



WARNING!

Health hazard!

Do not inhale any fuel fumes.



ENVIRONMENT!

Catch running out fuel, do not let it seep into the ground.

Dispose of the used fuel filter environmentally.

Changing the fuel pre-cleaner




Fig. 148

Unscrew the hose clamps ➞ Fig. 148 on the fuel pre-cleaner.


Pull the fuel filter out of the hoses.

Install the new fuel pre-filter and observe the flow direction (arrow).

Fasten the hose clamps.

Maintenance – Every 500 operating hours

Change the fuel filter cartridge



Slacken and unscrew the fuel filter cartridge ↩ Fig. 149.

Clean the sealing face on the filter carrier from any dirt.

Fig. 149

Apply a thin film of fuel to the seals and screw the new filter cartridge on hand-tight.

6.9.3 Check the anti-freeze concentration and the condition of the coolant



WARNING!

Danger of scalding!

Check the anti-freeze concentration only when the engine is cold.



NOTICE!

In order to avoid damage to the engine (e.g. by corrosion, cavitation and freezing), particular attention must be paid to the inspection of the coolant.

For coolant quality refer to the "table of fuels and lubricants".

Do not mix different coolants and additives, see section "Fuels and Lubricants - Coolant".

If the coolant is contaminated by corrosion residues or other suspended matter, flush the cooling system, see section "Changing the coolant".



ENVIRONMENT!

Collect coolant and dispose of it in an environmentally friendly way.




Fig. 150

Remove the cap  Fig. 150 from the coolant compensation tank and check the anti-freeze concentration with a conventional tester.

Check the condition of the coolant.

Screw the cap back on.

6.10 Every 1000 operating hours

6.10.1 Checking, adjusting the valve clearance



NOTICE!

We recommend to have this work carried out by trained personnel or our after sales service.

Check and adjust only when the engine is cold.

Cylinder 1 is on the flywheel side.

Valve clearance:

Intake and exhaust valve = 0.15 mm (0.006 in)

Remove the valve cover → Fig. 151.




Fig. 151




Fig. 152

Crankshaft position 1

IN	Intake valve
EX	Exhaust valve

Crank the engine until both valves on cylinder 1 are “overlapping”.

Perform the adjustment of the valve by following the adjustment diagram 1" → Fig. 152, black mark.

Check the gap between rocker arm and valve with a feeler gauge → Fig. 153.




Fig. 153




Fig. 154

Crankshaft position 2

IN	Intake valve
EX	Exhaust valve

Turn the crankshaft one revolution (360 °) further.

Perform the adjustment of the valve by following the adjustment diagram 2" → Fig. 154, black mark.

Install the cylinder head cover with a new gasket.



After a short test run check the engine for leaks.

6.10.2 Check the engine mounts




Fig. 155

Check air intake and exhaust manifold fastenings → Fig. 155 for tight fit.

Check sockets and clamps on the air filter for tight fit and leak tightness.

Check fastening and tightness of the lubrication oil sump.

Check condition and tight fit of engine mounts.

6.10.3 Check the travel control




Fig. 156

Move the travel lever → Fig. 156 forward, backwards and to braking position.

Thereby check for function, light movement, clearance and damage.

In case of malfunction perform trouble shooting and replace the corresponding parts.



NOTICE!

Only operate the machine after the travel control has been repaired.

6.11 Every 2000 operating hours

6.11.1 Changing hydraulic oil and breather filter

i *Perform this maintenance work at the latest after two years.*

i *See also the notes on the hydraulic system in the chapter "General notes on maintenance".*

Maintenance – Every 2000 operating hours



NOTICE!

The hydraulic oil must also be changed after major repairs in the hydraulic system.

Perform the oil change when the hydraulic oil is warm.

Replace the hydraulic oil filter element with every hydraulic oil change.

Change the filter only after the hydraulic oil change and after the test run.

Clean the area round hydraulic oil tank, filler opening and breather filter.

Do not start the engine after draining the hydraulic oil.

Do not use any detergents to clean the system.

Use only lint-free cleaning cloths.

For quality and quantity of oil refer to the "table of fuels and lubricants".

When changing from mineral oil based hydraulic oil to an ester based biologically degradable oil, you should consult the lubrication oil service of the oil manufacturer for details.



ENVIRONMENT!

Catch running out oil and dispose of environmentally.

i *Generally replace the hydraulic oil filter element after the test run.*

Drive the machine, until the hydraulic oil has reached operating temperature.

Shut down the engine, pull off the ignition key

Remove the cover from the hydraulic oil tank .




Fig. 157




Fig. 158




Fig. 159:



WARNING!

Danger of scalding!

When draining off hot hydraulic oil!

AD-/ADM-/ACM-machines: Disconnect the leak oil hose from the front right hand vibration motor, drain off and catch all hydraulic oil.

SC-/SCC-machines: Unscrew the leak oil return line at the right front inside the frame, route it to the outside and allow all hydraulic oil to run out and catch it.

Reconnect the leak oil hose tightly.

Maintenance – Every 2000 operating hours




Fig. 160




Fig. 161

Loosen the strap on the hydraulic oil tank and take it off with the cover.

Wipe the inside of the hydraulic tank clean with the lint-free cloth.

Attach the cover and tighten the strap.

i *We recommend to use our filling and filtering unit with fine filter to fill the system. This ensures finest filtration of the hydraulic oil, prolongs the life-time of the hydraulic oil filter and protects the hydraulic system.*

Fill in new hydraulic oil.

Check the hydraulic oil level in the inspection glass.

i *The breather filter for the hydraulic oil tank is integrated in the filler cap, you must therefore replace the complete filler cap.*

Close the tank with a new cap.

Perform a test run and check the system for leaks.

6.11.2 Replacing the hydraulic oil filter



Perform this maintenance work at the latest after two years.



WARNING!

Danger of scalding!

Danger of scalding by hot oil when unscrewing the oil filter.



NOTICE!

If the filter has to be changed together with the hydraulic oil, the filter must only be changed after the oil change and after the test run.

Do not use the oil in the filter bowl again.

Visible dirt may be an early sign for the failure of system components and indicate the possible failure of components. In this case determine the cause and replace or repair the defective components, if necessary. Negligence may cause destruction to the entire hydraulic system.

Do not clean or reuse the filter element.

Apart from the normal oil change intervals, the filter element must also be changed after major repairs in the hydraulic system.



ENVIRONMENT!

Catch running out oil, dispose of oil and filter element environmentally.




Fig. 162

Clean the area around the hydraulic oil filter.

Remove filter bowl (4) ↗ Fig. 162 with filter element (3).

Examine the surface of the filter element thoroughly for any visible dirt.

Take out the old filter element and clean filter bowl and thread.

Reassemble the filter bowl with a new filter element and new loop rings (1) and (2).

Changing the high pressure filter




Fig. 163

Clean the area around the high pressure filter ↗ Fig. 163.

Disconnect the high pressure oil lines from the high pressure filter.

Disassemble the high pressure filter and assemble the new high pressure filter, pay attention to the flow direction (arrow).

Connect and tighten the hydraulic lines.

After a short test run check hydraulic oil filter and high pressure filter leaks.

6.11.3 Changing the coolant



Perform this maintenance work at the latest after two years.



WARNING!

Danger of scalding!

Change the coolant only when the engine is cold.

Do not remove the radiator cap when the engine is still hot.

Always wear gloves when handling anti-freeze agent.



NOTICE!

Always screw the radiator cap tightly back on (second detent).

Always fill the engine cooling system with an anti-freeze mixture (corrosion protection).

Do not use more than 50% anti-freeze.

Do not mix different coolants and additives of any other kind. If necessary flush the cooling system 2-3 times with clear water.

For quality and quantity of coolant refer to the "table of fuels and lubricants".



ENVIRONMENT!

Catch running out coolant and dispose of environmentally.

Maintenance – Every 2000 operating hours




Fig. 164

Remove the radiator cap ↗ Fig. 164.




Fig. 165

Open the clamp (1) ↗ Fig. 165 and pull off the radiator hose.

Open the shut-off cock (2).

Drain the coolant completely off and collect it.

Close the drain tap again.

Assemble the coolant hose and tighten the clamp.

Check the condition of radiator hoses, if necessary replace all radiator hoses.




Fig. 166

Fill in coolant until the level reaches the bottom edge of the filler socket

↗ Fig. 166 .




Fig. 167

Fill in coolant up to the MAX mark
↪ Fig. 167.

Reattach the radiator cap and the cap of the compensation tank.

Start the diesel engine and run it warm to operating temperature.

Let the engine cool down and check the coolant level again, if necessary top up in the compensation tank.

6.11.4 Replacing the fuel lines



Perform this maintenance work at the latest after two years.



WARNING!
Fire hazard!

When working on the fuel system do not use open fire, do not smoke, do not spill any fuel.



WARNING!
Health hazard!

Do not inhale any fuel fumes.

Maintenance – Every 2000 operating hours



NOTICE!

For safety reasons this work should be performed every two years.

Hoses consist of rubber or plastic material and age over the course of time.



ENVIRONMENT!

Catch running out fuel, do not let it seep into the ground.

Replace all fuel hoses, including their hose clips.

6.11.5 Check the injection nozzles



NOTICE!

This work must only be performed by authorized service personnel.

6.12 Every 3000 operating hours

6.12.1 Check the fuel injection pump



NOTICE!

This work must only be performed by authorized service personnel.

6.13 As required

6.13.1 Checking the air pressure in the rubber tires

i Only on ACM/SCC-machines.




Fig. 168

Check the tire pressure with a pressure gauge → Fig. 168 on the tire valve.

i Ensure equal pressure in all rubber tires!

Nominal value 2 – 2.5 bar (29 – 36 psi)

6.13.2 Water sprinkler system, maintenance in case of frost

! NOTICE!

- If there is a risk of frost the water sprinkler system must be emptied or filled with an anti-freeze mixture.




Fig. 169

Open the rear flap, unscrew the screw plug for water provision → Fig. 169 and let all water run out (only AC machines).

Close the screw plug again.




Fig. 170

Fold up the covering hood ➞ Fig. 170.




Fig. 171

Route the hose to the outside. open the water drain tap ➞ Fig. 171 and let all water run out.

Close the drain tap again.




Fig. 172

Open the sprinkling system line connection ➞ Fig. 172 and let all water run out.

Switch on the pressure sprinkling system for a short while and drain the water from the pump.

Close the line connection again.




Fig. 173

Unscrew the water sprinkling nozzles ➞ Fig. 173 at front and rear and let all water run out.

Screw the nozzles back in before using the machine the next time.

6.13.3 Tightening torques for screws with metric unified thread

Bolt dimensions	Tightening torques Nm*		
	8.8	10.9	12.9
M4	3	5	5
M5	6	9	10
M6	10	15	18
M8	25	35	45
M10	50	75	83
M12	88	123	147
M14	137	196	235
M16	211	300	358
M18	290	412	490
M20	412	578	696
M22	560	785	942
M24	711	1000	1200
M27	1050	1480	1774
M30	1420	2010	2400

Fig. 174

* Strength classes for screws with untreated, non-lubricated surface. Screw quality designations are stamped on the screw heads.

8.8 = 8G

10.9 = 10K

12.9 = 12K

The values result in a 90% utilization of the screw's yield point at a coefficient of friction $\mu_{\text{total}} = 0.14$.

Compliance with the tightening torques is checked with torque wrenches.

When using MoS_2 lubricants the specified tightening torques do not apply.

i *Self locking nuts must always be replaced by new ones after they have been unscrewed.*

6.13.4 Measures to be applied for longer periods of rest

Before you take the engine out of service for longer than just a few months you should clean the machine from any dirt and check the anti-freeze concentration is sufficient.

Drain off dirty engine oil, fill in new oil and run the engine for approx. 5 minutes, so that the oil is distributed to all parts.

Check all screws and nuts and tighten these, if this should be necessary.

Remove the battery, fill up the acid level and charge it.

If the engine is not to be used for a longer period of time, run it every 2 to 3 months for about 5 minutes, to rule out the formation of rust.



NOTICE!

- If the stored engine is not run at regular intervals, moisture in the air may condensate and settle on moving engine parts, which will finally lead to corrosion.

If you have forgotten to run the engine over a period of more than 5 to 6 months apply a sufficient amount of engine oil to the valve guidance and the valve stem seal and make sure that the valves move without friction before you start the engine.

Park the machine on level ground and pull out the ignition key.

Do not store the machine in a place with combustible materials like hay or straw.

Only cover the machine after the engine has cooled down.

7.1 General notes

Please observe strictly the safety regulations in the corresponding section of these operating and maintenance instructions.

Malfunctions are frequently caused by incorrect operation of the machine or insufficient maintenance. Whenever a fault occurs you should therefore thoroughly read these instruction on correct operation and maintenance.

If you cannot locate the cause of a fault or rectify it yourself by following the trouble shooting chart, you should contact our customer service department.

7.2 Starting with jump wires



Fig. 175

Fold the cover on the battery compartment
↪ Fig. 175 to the front.




Fig. 176



NOTICE!

A wrong connection will cause severe damage in the electric system.

Bridge the machine only with a 12 Volt battery.

When jump starting with an external battery connect both plus poles first.

Then connect the ground cable first to the minus pole of the current supplying battery and then to engine or chassis ground, as far away from the battery as possible ↪ Fig. 176.

Start as described in section "Starting the engine" .

Once the engine is running switch on a powerful consumer (working light, etc.).



NOTICE!

- If no powerful consumer is switched on voltage peaks may occur when separating the connecting cables between the batteries, which could damage electrical components.

After starting disconnect the negative poles (ground cable) first and the positive poles after.

Switch off the consumer.

7.3 Engine problems

Fault description	Cause	Remedy
No or poor starting of engine	Fuel tank empty	Fill fuel tank
	Fuel filter clogged, in winter due to paraffin separation	Change the fuel filter, use winter fuel
	Fuel lines leaking	Check all line connections for leaks and tighten the fittings, bleed the fuel system
	Water in the fuel system	Cleaning the water separator.
	Travel lever not in parking brake position	Return the travel lever to parking brake position.
	Battery discharged or not connected, battery power too low	Charge the battery, clean the terminal clamps, tighten and cover them with acid-free grease, have battery tested
	Emergency stop push button is locked	Unlock the emergency stop switch
	Especially in winter: use of too viscous engine oil	Use the correct engine oil for the ambient temperatures
Engine runs irregularly with poor power	Fuel supply too low, fuel system clogged by paraffin separation (winter operation)	Change the fuel filter, check line connections for leaks and tighten fittings, use winter fuel under cold conditions.

Trouble shooting – Engine problems

Fault description	Cause	Remedy
	Injection valve or injection pump defective	Have examined by a specialist
	Air filter dirty	Clean the air filter, replace if necessary.
	Excessive play in throttle cable	Adjust the throttle cable, replace if necessary
Engine loses power and speed, excessive exhaust smoke	Engine oil level too high	Drain the oil down to the top dipstick mark
	Poor quality fuel	Use specified fuel
	Air filter dirty	Clean the air filter, replace if necessary.
	Injection nozzle defective	Have examined by a specialist
Engine overheating, engine must be shut down immediately!	Radiator heavily soiled	Clean the cooling fins
	Coolant level too low	Fill up coolant, check for leaks
	Injection nozzle defective	Have examined by a specialist
	Engine oil level too low	Fill up oil down to the top dipstick mark
	V-belt loose or broken	Tension or replace the V-belt
	Radiator internally corroded	Replace the radiator, flush the cooling system
	Thermostat defective	Check the thermostat, replace if necessary.

7.4 Fuse assignment

7.4.1 Notes on safety



WARNING!

Danger of injury by fire in the machine!

- Do not use fuses with higher ampere ratings and do not bridge fuses.

7.4.2 Central electrics




Fig. 177

Unscrew the fastening screws and fold out the central electrics against the end stop.



The printed circuit board is a equipped with a fuse test socket (Fuse Test). When plugging in an intact fuse an LED lights up.

	F241 15A		F03 10A
	F274 10A		F139 30A
	F119 10A		F275 5A
	F153 10A		F48 40A
	Pot. 30 F68 10A		F10 10A
	F23 10A		F09 10A
	F06 5A		F157 30A
	F30 10A		F45 10A
	F11 15A		F37 10A
	F12 15A		F05 10A
	F156 15A		F276 10A
	F08 15A		F04 7,5A
	F07 15A		JP1 5A
	F103 10A		

Fig. 178

Trouble shooting – Fuse assignment

Fuse	Amperage	Designation
F241	15 A	Optional headlights
F274	10 A	Precision spreader / hydraulic breaker
F119	10 A	Motor
F153	10 A	Potential 15
F68	10 A	Potential 30
F23	10 A	Warning horn
F06	5 A	Interval switch for pressure sprinkling system
F30	10 A	Potential 15
F11	15 A	Headlights, left
F12	15 A	Headlights, right
F156	15 A	Lighting
F08	15 A	Direction indicators and working head lights
F07	15 A	Hazard light system
F103	10 A	Potential 15
F03	10 A	Vibration
F139	30 A	Engine solenoid
F275	5 A	Economizer
F48	40 A	Preheating system
F10	10 A	Parking and tail light, right
F09	10 A	Parking and tail light, left
F157	30 A	Starter
F45	10 A	Edge cutter
F37	10 A	Sprinkling pump
F05	10 A	12 V socket
F276	10 A	Pump for emulsion sprinkling system
F04	7.5 A	Instruments
JP1	5 A	Vibration also with travel lever in position "II"

7.4.3 Main battery fuse




Fig. 179

Fuse	Amperage	Designation
F00	80 A	Main battery fuse

8.1 Final shut-down of machine

If the machine can no longer be used and needs to be finally shut down you must carry out the following work and have the machine disassembled by an officially recognized specialist workshop.



WARNING!

Danger of cauterisation ! Danger of explosion!

When working on the battery do not use open fire, do not smoke!

The battery contains acid. Do not let acid come in contact with skin or clothes!

Wear protective clothing!

Remove the batteries and dispose of in compliance with legal regulations.



ENVIRONMENT!

Collect all fuels and lubricants, do not let them seep into the ground and dispose of in compliance with legal regulations.

Empty the fuel tank.

Drain the hydraulic oil tank.

Drain coolant from engine and cooling system.

Drain the lubrication oil from the engine.

Disposal – Final shut-down of machine



WARNING!

Danger of explosion!

Parts that previously contained combustible fluids must not be cut with a cutting torch.

Head Office/Hauptsitz
BOMAG
Hellerwald
D-56154 Boppard
Germany
Telefon: +49 6742 100-0
Fax: +49 6742 3090
e-mail: info@bomag.com



BOMAG
Niederlassung Berlin
Gewerbestraße 3
15366 Hoppegarten
GERMANY
Tel.: +49 3342 369410
Fax: +49 3342 369436
e-mail: nlberlin@bomag.com

BOMAG
Niederlassung Boppard
Hellerwald
56154 Boppard
GERMANY
Tel.: +49 6742 100360
Fax: +49 6742 100392
e-mail: nlboppard@bomag.com

BOMAG
Niederlassung Chemnitz
Querstraße 6
09247 Chemnitz
GERMANY
Tel.: +49 3722 51590
Fax: +49 3722 515951
e-mail: nlchemnitz@bomag.com

BOMAG
Niederlassung Hannover
Dieselstraße 44
30827 Garbsen-Berenbostel
GERMANY
Tel.: +49 5131 70060
Fax: +49 5131 6766
e-mail: nlhannover@bomag.com

BOMAG
Niederlassung München
Otto-Hahn-Ring 3
85301 Schweitenkirchen
GERMANY
Tel.: +49 8444 91840
Fax: +49 8444 918420
e-mail: nlmuenchen@bomag.com

BOMAG
Niederlassung Stuttgart
Uferstraße 22
73630 Remshalden-Grunbach
GERMANY
Tel.: +49 7151 986293
Fax: +49 7151 9862959
e-mail: nlstuttgart@bomag.com

BOMAG Maschinenhandelsgesellschaft m.b.H.
Klausenweg 654
2534 Alland
AUSTRIA

Tel.: +43 2258 20202
Fax: +43 2258 20202-20
e-mail: austria@bomag.com

BOMAG MARINI EQUIPAMENTOS LTDA
Rua Comendador Clemente Cifali, 530
Distrito Industrial Ritter
Cachoeirinha – RS
BRAZIL
ZIP code 94935-225
Tel.: +55 51 2125-6677
Fax: +55 51 3470-6220
e-mail: brasil@bomag.com

BOMAG (CANADA), INC.
3455 Semenyk Court
Mississauga, Ontario
L5C 4P9
CANADA
Tel.: +1 905 361 9961
Fax: +1 905 361 9962
e-mail: canada@bomag.com

BOMAG (China) Construction
Machinery Co., Ltd
No. 2808, West Huancheng Road,
Shanghai Comprehensive Industrial
Zone Fengxian Shanghai 201401
CHINA
Tel.: +86 21 3365 5566
Fax: +86 21 3365 5508
e-mail: china@bomag.com

BOMAG France S.A.S.
2, avenue du Général de Gaulle
91170 VIRY-CHATILLON
FRANCE
Tel.: +33 1 69578600
Fax: +33 1 69962660
e-mail: france@bomag.com

BOMAG (GREAT BRITAIN), LTD
Sheldon Way, Larkfield
Aylesford
Kent ME20 6SE
GREAT BRITAIN
Tel.: +44 1622 716611
Fax: +44 1622 710233
e-mail: gb@bomag.com

BOMA Equipment Hong Kong LTD
Room 1003, 10/F Charm Centre
700, Castle Peak Road
Kowloon,
HONG KONG
Tel.: +852 2721 6363
Fax: +852 2721 3212
e-mail: bomahk@bomag.com

BOMAG Italia Srl.
Via Roma 50
48011 Alfonsine
ITALY
Tel.: +39 0544 864235
Fax: +39 0544 864367
e-mail: italy@bomag.com

FAYAT BOMAG Polska Sp. z o.o.
Ul. Szyszkowa 52
02-285 Warszawa
POLAND
Tel.: +48 22 4820400
Fax: +48 22 4820401
e-mail: poland@bomag.com

FAYAT BOMAG Rus OOO
Klyazma block, h 1-g
141400 Khimki, Moscow region
RUSSIA
Tel.: +7 (495) 2879290
Fax: +7 (495) 2879291
e-mail: russia@bomag.com

BOMAG GmbH, Singapore
300, Beach Road
The Concourse, , 18-06
Singapore 199555
SINGAPORE
Tel.: +65 294 1277
Fax: +65 294 1377
e-mail: singapore@bomag.com

BOMAG Americas, Inc.
125 Blue Granite Parkway
Ridgeway SC 29130
U.S.A.
Tel.: +1 803 3370700
Fax: +1 803 3370800
e-mail: usa@bomag.com